

BLIND MOUNT VISORS

Fits models W900B, W900L, T300, T400, T600 and T800. 4555 series replaces 3 bracket factory visor. Will not replace fiberglass visors. (Kit)

A. CURVED WINDSHIELD [2006 & EARLIER]

For trucks with Stainless Steel Mirror Brackets. For trucks with cast mirror brackets, [see page 126](#).

13" Blind Mount Drop Visor

45550 N45550

13" Blind Mount Louvered Drop Visor

45550L N45550L

Blind Mount Monster Drop Bow-Tie Visor

45551 N45551

10" Blind Mount Drop Visor

45552 N45552

Regular Drop Blind Mount Bow-Tie Visor

45553 N45553



A

Blind Mount Curved Windshield

B. FLAT WINDSHIELD [1999-2005]

For trucks with stainless steel mirror brackets. For trucks with cast mirror brackets, [see page 126](#).

12" Blind Mount Drop Visor

45530 N45530

12" Blind Mount Louvered Drop Visor

45530L N45530L

Blind Mount Monster Drop Bow-Tie Visor

45531 N45531

10" Blind Mount Drop Visor

45532 N45532

Regular Drop Blind Mount Bow-Tie Visor

45533 N45533



B

Blind Mount Flat Windshield

STANDARD MOUNT VISORS

Fits Models W900B, W900L, T300, T400, T600 and T800. Will not replace fiberglass visors. (Kit)

FLAT WINDSHIELD

For trucks with Stainless Steel Mirror Brackets. For trucks with cast mirror brackets, [see page 126](#).

C. Monster Drop Bow-Tie Visor [1999-2005]

45031 N45031

Regular Drop Bow-Tie Visor [1999-2005]

45033 N45033

Monster Drop Bow-Tie Visor [2007 & Newer]
Fits trucks with 2 factory brackets.

45081 N45081

Regular Drop Bow-Tie Visor [2007 & Newer]
Fits trucks with 2 factory brackets.

45083 N45083

D. 12" Drop Visor [1999-2005]

45030 N45030

12" Louvered Drop Visor [1999-2005]

45030L N45030L

10" Drop Visor [1999-2005]

45032 N45032

13" Drop Visor [2007 & Newer]
Fits trucks with 2 factory brackets.

45080 N45080

13" Louvered Drop Visor [2007 & Newer]
Fits trucks with 2 factory brackets.

45080L N45080L

10" Drop Visor [2007 & Newer]

Fits trucks with 2 factory brackets.

45082 N45082

E. FLAT WINDSHIELD [1985-1998]

Fits Models W900B, W900L, T300, T400, T600 and T800. Replaces Fiberglass or Stainless visor. (Kit)

12" Drop Visor (Shown)

45010 N45010

12" Louvered Drop Visor

45010L N45010L

Monster Drop Bow-Tie Visor

45011 N45011

9" Drop Visor

45012 N45012

Regular Drop Bow-Tie Visor

45013 N45013



C

Standard Mount Flat Windshield Bow-Tie Visor



D

Standard Mount 13" Drop Visor



E

Standard Mount Flat Windshield Drop Visor

See page 127 to replace fiberglass visors.



CURVED WINDSHIELD STANDARD MOUNT VISORS

Fits models W900B, W900L, T300, T400, T600 and T800. Must have stainless steel mirror brackets. Will not replace fiber glass. Must have factory visor brackets.

F. 13" Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45050 N45050

G. 13" Louvered Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45050L N45050L

13" Louvered Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45070L N45070L

13" Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45070 N45070

H. Monster Drop Bow-Tie Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45051 N45051

Monster Drop Bow-Tie Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45071 N45071

I. 10" Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45052 N45052

Regular Drop Bow-Tie Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45053 N45053

10" Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45072 N45072

Regular Drop Bow-Tie Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45073 N45073

REPLACEMENT VISORS FOR CURVED AND FLAT WINDSHIELDS

Fits models W900B, W900L, T300, T400, T600 and T800. Fits all curved windshields, with 3 factory brackets & flat windshields. [1999-2005] (Kit)

Replaces factory stainless visor must have 3 bracket factory visor. Must have factory brackets. Will not replace fiberglass visor.

To replace fiberglass visors see page 127.

Replacement Visor
45000 N45000

J. Replacement Extended Visor
45001 N45001

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

CURVED WINDSHIELD STANDARD MOUNT VISOR

Fits trucks with factory fiberglass visor or trucks without a factory visor.

10" DROP VISOR FITS TRUCKS WITH CAST MIRROR BRACKETS

Blank (0)	45620	N45620
SuperNova (6)	45621	N45621
Crew (6)	45623	N45623
2" Round Flat (10)	45624	N45624
2" Round Beehive (10)	45625	N45625
Challenger (10)	45629	N45629
Bulls-Eye (10)	45630	N45630
Fusion (10)	45631C	N45631C
M1 (6)	45621M1	N45621M1
M3 (10)	45624M3	N45624M3
M5 (10)	45629M5	N45629M5



Standard Mount 13" Curved Windshield Drop Visor with Bulls-Eye Lights

A. 13" DROP VISOR FITS TRUCKS WITH CAST MIRROR BRACKETS

Blank (0)	45600	N45600
SuperNova (6)	45601	N45601
Crew (6)	45603	N45603
2" Round Flat (10)	45604	N45604
2" Round Beehive (10)	45605	N45605
Challenger (10)	45609	N45609
Bulls-Eye (10)	45610	N45610
Fusion (10)	45611C	N45611C
M1 (6)	45601M1	N45601M1
M3 (10)	45604M3	N45604M3
M5 (10)	45609M5	N45609M5



10" DROP VISOR FITS TRUCKS WITH STAINLESS STEEL MIRROR BRACKETS

Blank (0)	45660	N45660
SuperNova (6)	45661	N45661
Crew (6)	45663	N45663
2" Round Flat (10)	45664	N45664
2" Round Beehive (10)	45665	N45665
Challenger (10)	45669	N45669
Bulls-Eye (10)	45670	N45670
Fusion (10)	45671C	N45671C
M1 (6)	45661M1	N45661M1
M3 (10)	45664M3	N45664M3
M5 (10)	45669M5	N45669M5

13" DROP VISOR FITS TRUCKS WITH STAINLESS STEEL MIRROR BRACKETS

Blank (0)	45640	N45640
SuperNova (6)	45641	N45641
Crew (6)	45643	N45643
2" Round Flat (10)	45644	N45644
2" Round Beehive (10)	45645	N45645
Challenger (10)	45649	N45649
Bulls-Eye (10)	45650	N45650
Fusion (10)	45651C	N45651C
M1 (6)	45641M1	N45641M1
M3 (10)	45644M3	N45644M3
M5 (10)	45649M5	N45649M5

CURVED WINDSHIELD STANDARD MOUNT VISOR

REPLACES FACTORY STAINLESS STEEL VISOR WITH 3 BRACKETS AND CAST MIRRORS. (2006 & Earlier)

13" Drop Visor	45055	N45055
Monster Drop Bow Tie	45056	N45056
10" Drop Visor	45057	N45057
Regular Drop Bow Tie	45058	N45058

REPLACES FACTORY STAINLESS STEEL VISOR WITH 2 BRACKETS AND CAST MIRRORS. (2007 & NEWER)

13" Drop Visor	45075	N45075
Monster Drop Bow Tie	45076	N45076
10" Drop Visor	45077	N45077
Regular Drop Bow Tie	45078	N45078



W900A VISOR [1975 & Newer]

- B.** 12" Drop Visor
45370 **N45370**

- 9" Drop Visor
45372 **N45372**

- C.** Monster Drop Bow-Tie Visor
45371 **N45371**

- Regular Drop Bow-Tie Visor
45373 **N45373**

- D.** **FIBERGLASS VISOR INSERT** [1985 & Newer]
Fits Models W900B, W900L, T300, T400, T600 and T800. Fits 1 And 2 Piece Curved Windshields.

Fiberglass Insert with 9 Challenger Lights and Bezels
40160B N40160B

- E.** **K100 CAB OVER VISOR**
K100 Blind Mount 11" Drop Visor
45090 N45090



N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.