



F

TOP OF DOOR TRIM
Chopped look. (Pair)

F. POLISHED FINISH

1 - 5" - Fits cab mounted mirrors. [2005 & Newer]

30434 N30434

5" - Fits door mounted mirrors. [1973-2004]

30436 N30436

6" - Fits cab mounted mirrors. [2005 & Newer]

30426 N30426

6" - Fits door mounted mirrors. [1973-2004]

30428 N30428

G. SANDED FINISH

1 - 5" - Fits cab mounted mirrors. [2005 & Newer]

30433 N30433

5" - Fits door mounted mirrors. [1973-2004]

30435 N30435

6" - Fits door mounted mirrors. [1973-2004]

30427 N30427

6" - Fits cab mounted mirrors. [2005 & Newer]

30425 N30425

WINDOW AIR DEFLECTORS
(Pair)

WITH TOP OF DOOR TRIM

Fits sloped door. For use with 5" Top of Door trim, 30433 and 30434. [2006 & Newer]

30437 N30437

2 - Fits straight door. For use with 5" Top of Door trim, 30433, 30434, 30435 and 30436. [1973-2005]

30432 N30432

Fits sloped door. For use with 6" Top of Door trim, 30425, 30426, 30427 and 30428. [2006 & Newer]

30424 N30424

Fits straight door. For use with 6" Top of Door trim, 30425, 30426, 30427 and 30428. [1973-2005]

30423 N30423

WITHOUT TOP OF DOOR TRIM

Fits sloped door. [2006 & Newer]

30429 N30429

Fits straight door. [1973-2005]

30430 N30430

UPPER DOOR / UNDER WINDOW TRIM

Fits 325, 330, 335, 337, 340, 347, 348, 357, 365, 367, 375, 377, 378, 379, 382, 384, 385, 388 and 389. (Pair)

Behind Mirror Bracket, rivet mount. [1973-2005]

30149 N30149

3 - Fits straight door, rivet mount. [2005]

30159 N30159

Fits straight door, tape mount. [2005]

30166 N30166

Fits sloped door, rivet mount. [2006 & Newer]

30169 N30169

Fits sloped door, tape mount. [2006 & Newer]

30178 N30178



G

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.