



567 SET BACK AXLE - PUNCHED AIR INTAKE SCREENS

Replace **XX** in the part number with a style from the punch options table. (Pair)

- 567 Punched Air Intake Screens
C. 39916-XX N39916-XX

PUNCH OPTIONS

View punch styles inside back cover.

- 23 Small 1/4" Circles
- 24 Large 7/16" Circles
- 28 Hexagons
- 30 Horizontal Rectangles
- 31 Vertical Rectangles
- 32 5/16" In-Line Squares
- 33 5/16" Offset Squares
- 36 Horizontal Oval Holes
- 37 Vertical Ovals
- 38 Horizontal 3/16" Oblong
- 39 Vertical 3/16" Oblong
- 40 Horizontal 5/16" Oblong
- 41 Vertical 5/16" Oblong
- 46 Stars
- 47 Snake Skin

567 SET BACK AXLE - FENDER LIGHT TRIMS (Pair)

- Fender Light Trims
D. 39019 N39019

DOOR HANDLE TRIMS (Pair)

- Door Handle Trims
E. 39000 N39000

567 SET BACK AXLE / 579 HOOD STRAP TRIMS (Kit)

- 567 Hood Strap Trims
F. 38026 N38026
 579 Hood Strap Trims
38025 N38025

TOP OF DOOR TRIMS
 Chopped look. (Pair)

POLISHED FINISH

- 8 Inch Top of Door Trim
G. 39020 N39020
 8 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout
39020MD N39020MD
 6 Inch Top of Door Trim
39021 N39021
 6 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout
39021MD N39021MD

SANDED FINISH

- 8 Inch Top of Door Trim
39022 N39022
 8 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout
39022 N39022
 6 Inch Top of Door Trim
39023 N39023
 6 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout
39023 N39023

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.