



ABOVE DOOR TRIMS - Fits Classic/FLD Condo (Pair)

- E.** 1 - Cab mounted mirrors (Tape Mount)
20070 N20070
 Door mounted mirrors (Tape Mount)
20072 N20072

ABOVE DOOR TRIMS - Fits Classic/FLD Mid-roof (Pair)

- Cab mounted mirrors (Tape Mount)
20074 N20074
 Cab mounted mirrors (Rivet Mount)
20075 N20075
F. 1 - Door mounted mirrors (Tape Mount)
20076 N20076
 Door mounted mirrors (Rivet Mount)
20077 N20077



ABOVE DOOR TRIMS Fits Century/Columbia [2003 & Earlier] (Pair)

- Rear Stack (Tape Mount)
G. 23077-11 N23077-11
 Side Stack (Tape Mount)
23177-11 N23177-11
 Rear Stack (Tape Mount)
H. 23080 N23080
 Side Stack (Tape Mount)
23180 N23180

To keep your equipment looking great use RoadWorks Detail Products, seen on pages 314-317.



N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.