

# PETERBILT

## 579 CAB DOOR TRIMS, DEF TRIMS

### 579 / 567 TOP OF DOOR TRIMS

Chopped look. (Pair)

#### POLISHED FINISH

##### A. 1 - 8 Inch Top of Door Trim

**39020**      **N39020**

8 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout

**39020MD**    **N39020MD**

6 Inch Top of Door Trim

**39021**      **N39021**

6 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout

**39021MD**    **N39021MD**

#### SANDED FINISH

8 Inch Top of Door Trim

**39022**      **N39022**

8 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout

**39022**      **N39022**

6 Inch Top of Door Trim

**39023**      **N39023**

6 Inch Top of Door Trim - No Passenger Side Upper Door Mirror Cutout

**39023**      **N39023**

### 579 / 567 UPPER DOOR / UNDER WINDOW TRIMS (Pair)

2 - Door Mounted Mirrors, tape mount.

**39060**      **N39060**

Go to pages 132 - 133 for 579 Cab Panels.

### 579 / 567 HANDLE AND DOOR TRIMS (Pair)

Handle And Door Trim

**B. 39005**      **N39005**

Handle Trim

**C. 39000**      **N39000**

### 579 DEF ACCESSORIES (Each)

##### D. 1 - DEF Tank Cap - Chromed Plastic

**30849**

2 - Fairing DEF fill Area Trim with Cutout

**N39010**

Fairing DEF Fill Area Trim no Cutout

**N39011**

To keep your equipment looking great use RoadWorks Detail Products, seen on pages 314 - 317.

