

ENTRY GRAB HANDLE TRIMS (Pair)

- A. 1** - 384 / 386 Entry Grab Handle Trims
Fits truck with rear or horizontal exhaust.
30810 N30810

UPPER DOOR / UNDER WINDOW TRIMS [2006 & Newer] (Pair)

- 2** - Cab Mounted Mirrors, rivet mount.
30169 N30169
Cab Mounted Mirrors, tape mount.
30178 N30178

WINDOW AIR DEFLECTORS Fits sloped door. [2006 & Newer] (Pair)

- 3** - Window Air Deflectors
30429 N30429

LATCH TRIMS [2006 & Newer] (Pair)

- 4** - Door Latch Surrounds
30581 N30581
5 - Door Latch Covers
30580 N30580

WINDOW TRIMS [2005 & Newer] (Each)

- 6** - View Window Trim
30152 N30152

386 PUNCHED CAB AIR INTAKE SCREEN With 7/16" Circle Holes. (Each)

- 7** - Passenger Side
30820-24 N30820-24
Driver Side Dummy
30821-24 N30821-24

DIMPLED UNDER DOOR PANELS Fits 386 with rear or horizontal exhaust.

- 8** - Tape mount (Pair)
30800 N30800

384, 386 AND 387 BATTERY / TOOL BOX TRIMS

- 9** - Top Replacement Step (Each)
30912 N30912
10 - Battery / Tool Box Door Covers (Pair)
30907 N30907
11 - Lower replacement step (Each)
30913 N30913

HOOD STRAP TRIM FITS 386. (Pair)

- Hood Strap Trim
B. 30811 N30811

