

UPPER DOOR / UNDER WINDOW TRIMS

- Center pieces only. Fits sleeper trucks. (Pair)
- A.** 30904 N30904
Fits day cabs. (6-piece kit)
- B.** 30904-06 N30904-06
End Pieces Only (4-piece kit)
30904-04 N30904-04
Center and End Pieces Fits sleeper trucks.
(4-piece kit)
- C.** 30908 N30908

VIEW WINDOW TRIM (Each)

- View Window Trim
- D.** 30902 N30902
View Window Trim With Flames
30903 N30903

HEADLIGHT TRIMS (Pair)

- Under Headlight Trims
- E.** 30906 N30906

LATCH TRIMS [2006 & Newer] (Pair)

- Door Latch / Key Hole Covers
- F.** 30580 N30580
Door Latch / Key Hole Surround
30581 N30581

REAR FRAME REPLACEMENT STEPS

Replaces all 13.75" wide step models. Reuses factory side gussets. (Each)

- Replacement Step
- G.** 34850-01 N34850-01

FAIRING INSERT (6-piece Kit)

- Premium Sleeper
- H.** 30918 N30918
Standard Sleeper
30919 N30919

