

PETERBILT

387 CAB AND SLEEPER PANELS

387 CAB PANELS - Fits sleeper trucks. Will not fit day cabs. Mounts to the bottom of the door. (Pair)

	Blank (0)	36600	N36600
	Supernova (6)	36601	N36601
	Crew (6)	36603	N36603
A.	2" Round Flat (12)	36604B	N36604B
	2" Round Beehive (12)	36605B	N36605B
	Challenger (12)	36609B	N36609B
	Bulls-Eye (12)	36610B	N36610B
	3/4" Button (12)	36610GB	N36610GB
	Fusion (12)	36611BC	N36611BC
	M1 (6)	36601M1	N36601M1
	M3 (12)	36604M3	N36604M3
	M5 (12)	36609M5	N36609M5
	Mini (12)	36609MN	N36609MN



387 DAY CAB PANELS - Will not fit sleeper trucks. Mounts to the bottom of the door. (Pair)

	Blank (0)	36620	N36620
	Supernova (8)	36621	N36621
B.	Crew (8)	36623	N36623
	2" Round Flat (12)	36624B	N36624B
	2" Round Beehive (12)	36625B	N36625B
	Challenger (12)	36629B	N36629B
	Bulls-Eye (12)	36630B	N36630B
	3/4" Button (12)	36630GB	N36630GB
	Fusion (12)	36631BC	N36631BC
	M1 (8)	36621M1	N36621M1
	M3 (12)	36624M3	N36624M3
	M5 (12)	36629M5	N36629M5
	Mini (12)	36629MN	N36629MN



387 SLEEPER PANELS - Sleeper Panels fit Stand-Up Sleeper models only. Does not fit Mid Roof or Low Roof models. (Pair)

STANDARD SLEEPER

	Blank (0)	37620	N37620
	Supernova (12)	37621	N37621
	Crew (12)	37623	N37623
	2" Round Flat (22)	37624B	N37624B
	2" Round Beehive (22)	37625B	N37625B
	Challenger (22)	37629B	N37629B
	Bulls-Eye (22)	37630B	N37630B
	3/4" Button (22)	37630GB	N37630GB
	Fusion (22)	37631BC	N37631BC
	M1 (12)	37621M1	N37621M1
	M3 (22)	37624M3	N37624M3
	M5 (22)	37629M5	N37629M5
	Mini (22)	37629MN	N37629MN



PREMIUM SLEEPER - (Includes heater plug hole on driver's side sleeper panel.)

	Blank (0)	37600	N37600
	Supernova (14)	37601	N37601
	Crew (14)	37603	N37603
C.	2" Round Flat (26)	37604B	N37604B
	2" Round Beehive (26)	37605B	N37605B
	Challenger (26)	37609B	N37609B
	Bulls-Eye (26)	37610B	N37610B
	3/4" Button (26)	37610GB	N37610GB
	Fusion (26)	37611BC	N37611BC
	M1 (14)	37601M1	N37601M1
	M3 (26)	37604M3	N37604M3
	M5 (26)	37609M5	N37609M5
	Mini (26)	37609MN	N37609MN



To identify a Premium Sleeper look for the extra section at the front of the sleeper area, located directly behind the curved section that meets the rear of the cab, and is separated from the rest of the sleeper by the vertical separations you see in the picture. Standard sleepers do not have the extra section.

Call RoadWorks Customer Service at 1-800-448-8741 for information on Sleeper Panels for Mid Roof and Low Roof model sleepers.