



587 SLEEPER TRUCK VISORS (Kit)

- 20" Drop Visor
- D. 35501 N35501**

- Monster Drop Bow-Tie Visor
- 35502 N35502**

- 18" Drop Visor
- 35510 N35510**

- Regular Drop Bow-Tie Visor
- 35511 N350511**



587 DAY CAB VISORS

Replaces factory visor. (Kit)

- 12" Drop Visor
- 35503 N35503**

- Monster Drop Bow-Tie Visor
- 35504 N35504**

- 10" Drop Visor
- 35512 N35512**

- Regular Drop Bow-Tie Visor
- 35513 N35513**

587 PUNCHED INTAKE SCREENS (Kit)

- E. 1 - Punched Intake Screen Replacement w/ Oval Holes**

- 30950-36 N30950-36**

PUNCH OPTIONS

View punch styles inside back cover.

- 23 Small 1/4" Circles
- 24 Large 7/16" Circles
- 28 Hexagons
- 30 Horizontal Rectangles
- 31 Vertical Rectangles
- 32 5/16" In-Line Squares
- 33 5/16" Offset Squares
- 36 Horizontal Oval Holes
- 37 Vertical Ovals
- 38 Horizontal 3/16" Oblong
- 39 Vertical 3/16" Oblong
- 40 Horizontal 5/16" Oblong
- 41 Vertical 5/16" Oblong
- 46 Stars
- 47 Snake Skin



UPPER DOOR / UNDER WINDOW TRIMS

- Center pieces only. Fits sleeper trucks. (Pair)
- F. 30904 N30904**
- Center and End Pieces. Fit sleeper trucks (4-piece kit)
- G. 30908 N30908**



587 BATTERY AND TOOL BOX TRIMS

- H. 1 - Lower Replacement Step (Each)**

- 30913 N30913**
- 2 - Battery / Tool Box Door Covers (Pair)**
- Fits 386, 387, and 587 Battery / Tool box doors with T handle

- 30740 N30740**
- 3 - Side Trims (4-piece kit)**

- 30960 N30960**
- 4 - Top Replacement Step (Each)**

- 30912 N30912**
- 5 - Above Battery / Tool Box Trims (6-piece kit)**

- 30961 N30961**

*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.