

PETERBILT

587 TRIMS

587 CAB PANELS

Fits sleeper trucks with fairings. Will not fit day cabs.
Mounts to cab. (Pair)

Blank (0)	38000	N38000
Supernova (6)	38001	N38001
Crew (6)	38003	N38003
2" Round Flat (8)	38004B	N38004B
2" Round Beehive (8)	38005B	N38005B
Challenger (8)	38009B	N38009B
Bulls-Eye (8)	38010B	N38010B
3/4" Button (8)	38010GB	N38010GB
Fusion (8)	38011BC	N38011BC
M1 (6)	38001M1	N38001M1
M3 (8)	38004M3	N38004M3
M5 (8)	38009M5	N38009M5
Mini (8)	38009MN	N38009MN

A.



587 SLEEPER PANELS

Sleeper Panels fit Stand-up Sleeper models only. Does not fit Mid Roof or Low Roof models. (Pair)

STANDARD SLEEPER

Blank (0)	38060	N38060
Supernova (12)	38061	N38061
Crew (12)	38063	N38063
2" Round Flat (20)	38064B	N38064B
2" Round Beehive (20)	38065B	N38065B
Challenger (20)	38069B	N38069B
Bulls-Eye (20)	38070B	N38070B
3/4" Button (20)	38070GB	N38070GB
Fusion (20)	38071BC	N38071BC
M1 (12)	38061M1	N38061M1
M3 (20)	38064M3	N38064M3
M5 (20)	38069M5	N38069M5
Mini (20)	38069MN	N38069MN

PREMIUM SLEEPER

Blank (0)	38040	N38040
Supernova (16)	38041	N38041
Crew (16)	38043	N38043
2" Round Flat (26)	38044B	N38044B
2" Round Beehive (26)	38045B	N38045B
Challenger (26)	38049B	N38049B
Bulls-Eye (26)	38050B	N38050B
3/4" Button (26)	38050GB	N38050GB
Fusion (26)	38051BC	N38051BC
M1 (16)	38041M1	N38041M1
M3 (26)	38044M3	N38044M3
M5 (26)	38049M5	N38049M5
Mini (26)	38049MN	N38049MN

B.



387/587 SHOCK COVERS (Kit)

C. 1 - (6) M3 Lights / Bezels
33297M3 N33297M3

For a complete list of lighting options and part numbers for Peterbilt 387 and 587 Shock Covers go to page 120.

