

BLIND MOUNT VISORS FOR FLAT WINDSHIELD [1999-2005]

Fits models W900B, W900L, T300, T400, T600 and T800. 4555 series replaces 3 bracket factory visor. For trucks with Stainless Steel Mirror Brackets. Will not replace fiberglass visors. (Kit)

See page 168 for trucks with cast mirror brackets.

Not sure which type of mirror you have? See images at bottom of page 169 for examples of cast mirror brackets and stainless mirror brackets.

12" DROP VISOR [Kit]

A. Blank (0)	45530	N45530
Louvered (0)	45530L	N45530L
B. 3/4 Button (10)	45530LT0	N45530LT0
Bulls-Eye (10)	45530LT1	N45530LT1

MONSTER DROP BOW-TIE DROP VISOR [Kit]

Monster Drop Bow-Tie	45531	N45531
----------------------	-------	--------

10" BLIND MOUNT DROP VISOR [Kit]

Blank (0)	45532	N45532
3/4 Button (10)	45532LT0	N45532LT0
Bulls-Eye (10)	45532LT1	N45532LT1

REGULAR DROP BOW-TIE DROP VISOR [Kit]

Regular Drop Bow-Tie Visor	45533	N45533
----------------------------	-------	--------

BLIND MOUNT VISORS FOR FLAT WINDSHIELD [1985-1998]

Fits Models W900B, W900L, T300, T400, T600 and T800. Replaces Fiberglass or Stainless visor.(Kit)

12" DROP VISOR [KIT]

C. Blank (0)	45020	N45020
Louvered (0)	45020L	N45020L
3/4 Button (10)	45020LT0	N45020LT0
D. Bulls-Eye (10)	45020LT1	N45020LT1

MONSTER DROP BOW-TIE DROP VISOR [Kit]

Monster Drop Bow-Tie	45021	N45021
----------------------	-------	--------

9" DROP VISOR [Kit]

Blank (0)	45022	N45022
3/4 Button (10)	45022LT0	N45022LT0
Bulls-Eye (10)	45022LT1	N45022LT1

REGULAR DROP BOW-TIE DROP VISOR [Kit]

Regular Drop Bow-Tie Visor	45023	N45023
----------------------------	-------	--------



See pages 167, 168, and 169 for visor options to replace fiberglass visors.

To keep your equipment looking great use RoadWorks Detail Products, pages 292 - 295.