



**E**

**T680 3 PIECE BLIND MOUNT REPLACEMENT BUMPER 17" OUTER / 13.5" CENTER. (Kit)**

Bumper Blank	49900-A	N49900-A
Tow Holes	49900-B	N49900-B
Step	49900-C	N49900-C
Recessed Plate	49900-D	N49900-D
Bumper - Tow Holes and Step	49900-E	N49900-E
Bumper - Tow Holes / Recessed Plate	49900-F	N49900-F
Bumper - Step / Recessed Plate	49900-G	N49900-G
Bumper - Tow Holes, Step, Recessed Plate	49900-H	N49900-H

**E.**



**F**

**T880 SET BACK AXLE - 18" 1 PIECE REPLACEMENT BUMPER (Kit)**

Bumper Blank, Upper Center Air Hole	49906-A	N49906-A
Tow Holes, Upper Center Air Hole	49906-B	N49906-B
Step, and Upper Center Air Hole	49906-C	N49906-C
Plate Holes, Upper Center Air Hole	49906-D	N49906-D
Tow Holes, Step, Upper Center Air Hole	49906-E	N49906-E
Tow Holes, Plate Holes, Upper Center Air Hole	49906-F	N49906-F
Step, Plate Holes, Upper Center Air Hole	49906-G	N49906-G
Tow Holes, Step, Plate Holes, Upper Center Air Hole	49906-H	N49906-H

**F.**

For T880S Set Forward Axle Trucks call RoadWorks Customer Service at 1-800-448-8741.



**G**

**T880 SET BACK AXLE - 18" 3 PIECE REPLACEMENT BUMPER (Kit)**

Bumper Blank, Upper Center Air Hole	49905-A	N49905-A
Tow Holes, Upper Center Air Hole	49905-B	N49905-B
Step, Upper Center Air Hole	49905-C	N49905-C
Plate Holes, Upper Center Air Hole	49905-D	N49905-D
Tow Holes, Step, Upper Center Air Hole	49905-E	N49905-E
Tow Holes, Plate Holes, Upper Center Air Hole	49905-F	N49905-F
Step, Plate Holes, Upper Center Air Hole	49905-G	N49905-G
Tow Holes, Step, Plate Holes, Upper Center Air Hole	49905-H	N49905-H

**G.**



**H**

**T880 SET BACK AXLE - UNDER BUMPER BAR FOR TAPERED BUMPER (Kit)**

<b>H.</b> 1 - Blank (0)	49890	N49890
SuperNova (8)	49891	N49891
Crew (8)	49892	N49892
Challenger (13)	49893	N49893
Bulls-Eye (13)	49894	N49894
Fusion (13)	49895	N49895
M1 (8)	49893M1	N49893M1
M3 (13)	49893M3	N49893M3
M5 (13)	49893M5	N49893M5
Mini (13)	49893MN	N49893MN
3/4" Button (13)	49894G	N49894G

**T880 SET BACK AXLE - LOWER FENDER BEHIND BUMPER TRIM (Pair)**

<b>2</b> - Lower Fender Behind Bumper Trim for Trucks without RoadWorks T880 Fender Guard installed.	49885	N49885
Lower Fender Behind Bumper Trim for Trucks with RoadWorks T880 Fender Guard installed.	49886	N49886

See page 203 for T880 Fender Guards.

**N** \*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.