

### SLEEPER WINDOW TRIMS

- A.** 1 - 86" Studio Sleeper Upper (Sliding) Window Trims, (Pair)  
**40116 N40116**
- 
- 2 - Sleeper Door Window Trims  
 Trims 1 window. (2-piece kit)  
**40115 N40115**
- 
- 3 - Rear Vertical Trim Covers  
 Fits rubber on sleeper wing extensions. (Pair)  
**40111 N40111**
- 
- Sleeper Door Window Trim On Window Frame (Each)  
**40115-01 N40115-01**
- 
- Sleeper Door Window Trim Surrounds Window Frame (Each)  
**40115-02 N40115-02**
- 
- Sleeper Door 4" Chopped Window Trims (Kit)  
**40115-400 N40115-400**
- 
- Sleeper Door 6" Chopped Window Trims (Kit)  
**40115-600 N40115-600**
- 
- Sleeper Door 8" Chopped Window Trims (Kit)  
**40115-800 N40115-800**
- 
- Sleeper Door Window 4" Chop Top Only (Each)  
**40110-400 N40110-400**
- 
- Sleeper Door Window 6" Chop Top Only (Each)  
**40110-600 N40110-600**
- 
- Sleeper Door Window 8" Chop Top Only (Each)  
**40110-800 N40110-800**
- 
- 86" Studio Sleeper Upper  
 Swing-out window trims. (Pair)  
**40117 N40117**
- 
- 72" Studio Sleeper Upper  
 Sliding or swing-out window trims. (Pair)  
**40119 N40119**



### 4.88" X 10.44" VENT COVERS (Each)

- Vent Covers, Flat  
**40098 N40098**
- 
- Vent Covers, with Sides  
**40100 N40100**
- 
- Vent Covers, Louvered with Sides  
**40099 N40099**



### 4.75" X 10.25" VENT COVERS (Each)

- Vent Covers, Flat  
**40095 N40095**
- 
- Vent Covers, Louvered with Sides  
**40096 N40096**
- 
- F.** 1 - Dimpled Vent Surround Trim, With Flames  
**40109 N40109**
- 
- G.** 1 - Dimpled Vent Surround Trim, Blank  
**40108 N40108**
- 
- 2 - Vent Covers, with Sides  
**40097 N40097**



### SLEEPER DOOR HANDLE TRIM

- Non-Daylite Studio Sleeper Storage And Cab trim (Pair)  
**H. 40113 N40113**

