

A - CURVED WINDSHIELD VISORS

Fits truck with factory fiberglass visor or truck without a factory visor. (Kit)

See page 180 for 13" Standard Mount Drop Visors.

See page 180 for 10" Standard Mount Drop Visors.

See page 180 for 13" Blind Mount Drop Visors.

See page 180 for 10" Blind Mount Drop Visors.

T660 PUNCHED INSERTS AND TRIMS

Replace **XX** in the part number with a style from the punch options table. (Each)

Options C and D replace factory black plastic screen.

B. 1 - T660 Punch Grille Insert

45380-XX N45380-XX

2 - T660 Lower Punch Grille Insert

45385-XX N45385-XX

Punched Intake and Logo Trim Screen

40819-XX N40819-XX

Replacement Punched Intake Trim Screen

D. **40820-XX N40820-XX**

PUNCH OPTIONS

View punch styles inside back cover.

-20	Keyholes
-23	Small 1/4" Circles (Shown)
-24	Large 7/16" Circles
-28	Hexagons
-30	Horizontal Rectangles
-31	Vertical Rectangles
-32	5/16" In-Line Squares
-33	5/16" Offset Squares
-36	Horizontal Ovals
-37	Vertical Ovals
-38	Horizontal 3/16" Oblong
-39	Vertical 3/16" Oblong
-40	Horizontal 5/16" Oblong
-41	Vertical 5/16" Oblong
-46	Stars
-47	Snake Skin

T660 GRILLE INSERTS

E. 1 - Louvered Grille Insert with 30 Louver Style Bars

49945 N49945

Call RoadWorks Customer Service for to find out about our New Billet Style Grille Inserts for Kenworth. See example on Page 185.

T660 3 PIECE BLIND MOUNT 18" REPLACEMENT BUMPER (Kit)

Bumper Blank

49907-A N49907-A

Tow Holes

49907-B N49907-B

Step

49907-C N49907-C

Recessed Plate

49907-D N49907-D

Bumper - Tow Holes and Step

49907-E N49907-E

2 - Bumper - Tow Holes / Recessed Plate

49907-F N49907-F

Bumper - Step / Recessed Plate

49907-G N49907-G

Bumper - Tow Holes, Step, Recessed Plate

49907-H N49907-H

UNDER HEADLIGHT AND GRILLE TRIMS

3 - Under Headlight and Grille Trims (3 pc kit)

40275 N40275



See page 180 for a full assortment of Blind Mount and Standard Mount Drop Visors for Kenworth T660.

