

### 9900I / IX EXTERIOR CAB ACCESSORIES (Pair)

- A.** 1 - I-Model Cab, Window Air Deflectors, 19.3" Tall  
50431 N50431  
2 - I-Model Cab, Front Of Side Window Triangle Trims  
50110 N50110  
3 - 5 Inch Polished Top of Door Trim  
For truck with passenger side door mirror.  
50420 N50420  
6 Inch Polished Top of Door Trim  
For truck with passenger side door mirror.  
50422 N50422
- B.** 1 - I-Model Cab, Under Window Trims  
50190 N50190
- C.** 1 - I-Model Cab, Passenger Side Replacement Hood Scoop (Kit)  
50900 N50900  
2 - 9900I / IX, 5900I Upper Hood Latch Trims  
50093 N50093  
I-Model Cab, Passenger Side Replacement Hood Scoop With Louvers (Kit)  
50900L N50900L
- D.** 1 - I-Model Cab, Behind Breather Turn Signal Trims  
50113 N50113  
2 - I-Model Cab, Lower Mirror Bracket Box Covers  
50111 N50111
- E.** 1 - I-Model Cab, Door Handle Surrounds w/ Dimples  
50440 N50440  
2 - I-Model Cab, Door Key Hole Trims  
50441 N50441  
Freedom Eagle Trims, 33.25" x 6.4"
- F.** 11826 N11826

