



**9900I / IX BATTERY, TOOL BOX TRIMS AND LOWER STEP BARS (Each)**

- G.** **1** - 48.3" Battery and Tool Box Cover With Hardware [2000-2004]  
**50070 N50070**
- 2** - Battery Or Tool Box Step Edge Trim 43" x 1.63"  
**50072 N50072**
- 3** - Battery Or Tool Box Step Edge Trim 46.25" x 1.63"  
**50073 N50073**
- 
- H.** **1** - 47.2" Lower Step Bars With Louvers (Pair)  
**54119 N54119**
- 2** - 48.3" Battery Or Tool Box Cover With Louvers and Hardware. [2000-2004]  
**50071 N50071**

**47.2" LOWER STEP BARS (Pair)**

|                          |                |                 |
|--------------------------|----------------|-----------------|
| Blank (0)                | <b>54100</b>   | <b>N54100</b>   |
| <b>I.</b> SuperNova (10) | <b>54101</b>   | <b>N54101</b>   |
| Crew (10)                | <b>54103</b>   | <b>N54103</b>   |
| 2" Round Flat (14)       | <b>54104B</b>  | <b>N54104B</b>  |
| 2" Round Beehive (14)    | <b>54105B</b>  | <b>N54105B</b>  |
| Challenger (14)          | <b>54109B</b>  | <b>N54109B</b>  |
| Bulls-Eye (14)           | <b>54110B</b>  | <b>N54110B</b>  |
| 3/4" Button (14)         | <b>54110GB</b> | <b>N54110GB</b> |
| Fusion (14)              | <b>54111BC</b> | <b>N54111BC</b> |
| M1 (10)                  | <b>54101M1</b> | <b>N54101M1</b> |
| M3 (14)                  | <b>54104M3</b> | <b>N54104M3</b> |
| M5 (14)                  | <b>54109M5</b> | <b>N54109M5</b> |
| Mini (14)                | <b>54109MN</b> | <b>N54109MN</b> |



**9900I / IX UNDER DOOR PANELS**

- J.** **1** - Fits I Model truck with sleeper. Tape mount. Will not fit day cab. (Pair)  
**50200 N50200**



See page 353 for information on ordering Millennium Glo Series lights on any RoadWorks lighted part.



**N** \*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.