

INTERNATIONAL

TRANSITION TRIMS / SIDE OF SLEEPER TRIMS

CAB TO SLEEPER TRANSITION TRIMS FITS TRUCKS WITHOUT SIDE FAIRINGS WITH REAR STACKS (Pair)

- A. **50068** **N50068**
Angle Under Cab-To-Sleeper Trim
- B. **50067** **N50067**
Straight Down Cab-To-Sleeper Trim

SIDE OF SLEEPER TRIMS

- C. **1** - Hi-Rise Pro Sleeper Rear Vertical Extension Trims (4-piece kit)
50117 **N50117**
- 2** - Vent Cover With Sides
5.25" x 12.25" (Each)
50097 **N50097**
- Louvered Vent Cover With Sides
5.25" X 12.25" (Each)
50096 **N50096**
- Lo-Roof Pro Sleeper Rear Vertical Extension Trims (Pair)
50116 **N50116**
- Pro Sleeper Door Handle Trims With Dimples (Pair)
50442 **N50442**
- D. **50442** **N50442**
- Hi-Rise Pro Sleeper Lower Rear Vertical Extension Trims (Pair)
50117-11 **N50117-11**
- E. **50117-11** **N50117-11**
- 'Fire Extinguisher Inside' Sign
19 1/5" x 2 2/3" (Each)
10878 **N10878**
- F. **10878** **N10878**
- Behind Grab Handle Trims With Dimples Mounts on Pro Sleepers.
50119 **N50119**
- G. **50119** **N50119**

