

PROSTAR FAIRING TRIMS (PAIR)

A. 1 - Long Fairing Trim, Under Door

51143 N51143

2 - Short Fairing Trim, Under Sleeper

51144 N51144

B. 1 - Top Fairing Trim Behind Cab Entry Step

51141 N51141

2 - Top Replacement Step

54902 N54902

3 - Bottom Replacement Step

54903 N54903

C. Fuel Fill Trim

51142 N51142

D. 1 - Front Top Fairing Trim

51140 N51140

