



PROSTAR CAB PANELS / HEATER PLUG HOLE

Fits truck with fairings and rear stack. (Pair)

Blank (0)	56100	N56100
SuperNova (8)	56101	N56101
Crew (8)	56103	N56103
2" Round Flat (12)	56104B	N56104B
2" Round Beehive (12)	56105B	N56105B
Challenger (12)	56109B	N56109B
E. Bulls-Eye (12)	56110B	N56110B
3/4" Button (12)	56110GB	N56110GB
Fusion (12)	56111BC	N56111BC
M1 (8)	56101M1	N56101M1
M3 (12)	56104M3	N56104M3
M5 (12)	56109M5	N56109M5
Mini (12)	56109MN	N56109MN

PROSTAR CAB PANELS / WITHOUT HEATER PLUG HOLE

Blank (0)	56120	N56120
SuperNova (8)	56121	N56121
Crew (8)	56123	N56123
2" Round Flat (12)	56124B	N56124B
2" Round Beehive (12)	56125B	N56125B
Challenger (12)	56129B	N56129B
Bulls-Eye (12)	56130B	N56130B
3/4" Button (12)	56130GB	N56130GB
Fusion (12)	56131BC	N56131BC
M1 (8)	56121M1	N56121M1
M3 (12)	56124M3	N56124M3
M5 (12)	56129M5	N56129M5
Mini (12)	56129MN	N56129MN



PROSTAR SLEEPER / 73" SLEEPER PANELS

Fits truck with fairing and rear stack. Comes with cab to sleeper transition. (Pair)

Blank (0)	57100	N57100
SuperNova (10)	57101	N57101
Crew (10)	57103	N57103
2" Round Flat (16)	57104B	N57104B
2" Round Beehive (16)	57105B	N57105B
Challenger (16)	57109B	N57109B
F. Bulls-Eye (16)	57110B	N57110B
3/4" Button (16)	57110GB	N57110GB
Fusion (16)	57111BC	N57111BC
M1 (10)	57101M1	N57101M1
M3 (16)	57104M3	N57104M3
M5 (16)	57109M5	N57109M5
Mini (16)	57109MN	N57109MN



PICTURED: PROSTAR CAB TO SLEEPER TRANSITION



See page 382 for information on ordering Millennium Glo Series lights on any RoadWorks lighted part.