



FLD FRONT BUMPER INSERTS

Tape Mount. (3-piece kit)

- E. 1 - 1 Tow-Pin Hole and Fog Light Holes.**
22070 N22070
- 2 - 1 Tow-Pin Hole and Blank Ends.**
22071 N22071
- 3 - 2 Step, Tow-Pin Hole and Fog Light Holes.**
22072 N22072
- 4 - 1 Step, 2 Tow-Pin Holes and Fog Light Holes.**
22073 N22073
- 5 - 1 Step, 2 Tow-Pin Holes and Blank Ends.**
22074 N22074
- 6 - Blank center and 2 Fog Light Holes.**
22075 N22075
- 7 - Blank**
22076 N22076

GRAB HANDLE TRIMS Fits Classic/FLD. (Pair)

- F. 1 - Sleeper Grab Handle Trims**
20099 N20099
- 2 - Cab Grab Handle Trims**
(Fits truck with rear stacks)
20106 N20106

DOOR HANDLE TRIMS

Fits Classic, FLD, Century, Columbia. (Pair)

- Blank
23090 N23090
- 3 - With Flames**
20459 N20459

VIEW WINDOW TRIMS Fits Classic/FLD. (Each)

- Blank
20104 N20104
- 4 - With Flames**
20105 N20105

WINDOW AIR DEFLECTORS Fits Classic/FLD. (Pair)

- 5 - Window Air Deflectors**
20430 N20430

UNDER WINDOW TRIMS Fits Classic/FLD. (Pair)

- 6 - Door Mounted Mirrors**
20147 N20147
- Cab mounted mirrors
20148 N20148

CLASSIC/FLD TOP OF DOOR TRIMS

Chopped look. (Pair)

POLISHED FINISH

- 7 - 5.75" - Fits door mounted mirrors.**
20410 N20410
- 5.75" - Fits cab mounted mirrors
20412 N20412
- 6.75" - Fits door mounted mirrors.
20414 N20414
- 6.75" - Fits cab mounted mirrors.
20416 N20416

SANDED FINISH

- 5.75" - Fits door mounted mirrors.
20411 N20411
- 5.75" - Fits cab mounted mirrors.
20413 N20413
- 6.75" - Fits door mounted mirrors.
20415 N20415
- 6.75" - Fits cab mounted mirrors.
20417 N20417



See page 13 for Above Door Trims.

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.