

**VT 880 CAB, COWL AND SLEEPER PANELS**

- A. 1 - Cab And Cowl**  
 26 Challenger Lights and Bezels (Kit)  
**76509B-02 N76509B-02**
- 
- 2 - Sleeper Panels**  
 20 Challenger Lights and Bezels (Pair)  
**77009B N77009B**
- 
- 3 - Lower Sleeper Window Trim**  
 (Pair)  
**70150 N70150**
- 
- 4 - Upper Sleeper Window Trim**  
 (Pair)  
**70151 N70151**

**CAB AND COWL (Kit)**

Blank (0)	<b>76500-02</b>	<b>N76500-02</b>
Supernova (16)	<b>76501-02</b>	<b>N76501-02</b>
Crew (16)	<b>76503-02</b>	<b>N76503-02</b>
2" Round Flat (26)	<b>76504-02B</b>	<b>N76504-02B</b>
2" Round Beehive (26)	<b>76505-02B</b>	<b>N76505-02B</b>
Challenger (26)	<b>76509-02B</b>	<b>N76509-02B</b>
Bulls-Eye (26)	<b>76510-02B</b>	<b>N76510-02B</b>
3/4" Button (26)	<b>76510-02GB</b>	<b>N76510-02GB</b>
Fusion (26)	<b>76511-02BC</b>	<b>N76511-02BC</b>
M1 (16)	<b>76501M1-02</b>	<b>N76501M1-02</b>
M3 (26)	<b>76504M3-02</b>	<b>N76504M3-02</b>
M5 (26)	<b>76509M5-02</b>	<b>N76509M5-02</b>
Mini (26)	<b>76509MN-02</b>	<b>N76509MN-02</b>

**77" SLEEPER PANELS (Pair)**

Blank (0)	<b>77000</b>	<b>N77000</b>
Supernova (10)	<b>77001</b>	<b>N77001</b>
Crew (10)	<b>77003</b>	<b>N77003</b>
2" Round Flat (20)	<b>77004B</b>	<b>N77004B</b>
2" Round Beehive (20)	<b>77005B</b>	<b>N77005B</b>
Challenger (20)	<b>77009B</b>	<b>N77009B</b>
Bulls-Eye (20)	<b>77010B</b>	<b>N77010B</b>
3/4" Button (20)	<b>77010GB</b>	<b>N77010GB</b>
Fusion (20)	<b>77011BC</b>	<b>N77011BC</b>
M1 (10)	<b>77001M1</b>	<b>N77001M1</b>
M3 (20)	<b>77004M3</b>	<b>N77004M3</b>
M5 (20)	<b>77009M5</b>	<b>N77009M5</b>
Mini (20)	<b>77009MN</b>	<b>N77009MN</b>

**OPTIONAL FUEL FILL ACCESS DOOR**

For information about different fuel fill locations please call RoadWorks customer service at 1-800-448-8741.



**CAB AND SLEEPER TRIMS (Pair)**

- B. 1 - Cab Door Handle Surrounds**  
**70000 N70000**
- 
- 2 - Sleeper Turn Light Trim**  
**70155 N70155**

