

GENERATION 2 VN CAB AND SLEEPER PANELS

[2004 & Newer] (Pair)

CAB PANELS

Blank (0)	76520	N76520
Supernova (6)	76521	N76521
A. Crew (6)	76523	N76523
Challenger (10)	76529B	N76529B
Bulls-Eye (10)	76530B	N76530B
3/4" Button (10)	76530GB	N76530GB
M1 (6)	76521M1	N76521M1
M3 (10)	76524M3	N76524M3
M5 (8)	76529M5	N76529M5
Mini (10)	76529MN	N76529MN

SLEEPER PANELS + EXTENSIONS

Blank (0)	77040	N77040
Supernova (14)	77041	N77041
B. Crew (14)	77043	N77043
Challenger (24)	77049B	N77049B
Bulls-Eye (24)	77050B	N77050B
3/4" Button (24)	77050GB	N77050GB
M1 (14)	77041M1	N77041M1
M3 (24)	77044M3	N77044M3
M5 (20)	77049M5	N77049M5
Mini (24)	77049MN	N77049MN

GENERATION 2 VN REPLACEMENT STEPS

[2004 & Newer] (Each)

C. Cab Entry Steps 28.5" long.	74000	N74000
D. 1 - Rear Top Fairing Step 16.5" long.	74001	N74001
2 - Inner Bottom Rear Step 13.5" long.	74002	N74002

VOLVO VT / VN DOOR HANDLE TRIMS

(Pair)

E. 1 - Cab Door Handle Surrounds	70000	N70000
2 - Cab Door Handle Covers	70001	N70001
Sleeper Door Handle Trim		
F. 74009	N74009	

VOLVO SLEEPER VENT TRIMS

(Each)

Volvo Sleeper Vent Cover	70800	N70800
--------------------------	--------------	---------------

To keep your equipment looking great use RoadWorks Detail Products, seen on pages 314-317.

