



**ABOVE DOOR TRIMS (Pair)**

- E. 1 - Tape Mount (Rear Stack) [2003 & Earlier]**  

<b>23077-11</b>	<b>N23077-11</b>	
(Side Stack)		
<b>23177-11</b>	<b>N23177-11</b>	
- F. 1 - Tape Mount (Rear Stack) [2003 & Earlier]**  

<b>23080</b>	<b>N23080</b>	
(Side Stack)		
<b>23180</b>	<b>N23180</b>	

**CENTURY / COLUMBIA TOP OF DOOR TRIMS**  
Chopped look. (Pair)

**POLISHED FINISH**

- 2 - 6" - Top of Door Trim**  

<b>23020</b>	<b>N23020</b>	
--------------	---------------	--
- 7" - Top of Door Trim**  

<b>23022</b>	<b>N23022</b>	
--------------	---------------	--

**SANDED FINISH**

- 6" - Top of Door Trim**  

<b>23021</b>	<b>N23021</b>	
--------------	---------------	--
- 7" - Top of Door Trim**  

<b>23023</b>	<b>N23023</b>	
--------------	---------------	--

**UNDER WINDOW TRIMS (Pair)**

- 3 - Side Door Accents**  

<b>23085</b>	<b>N23085</b>	
--------------	---------------	--

**SIDE COWL TRIMS (Pair)**

- 4 - Columbia (2003 & Earlier)**  

<b>23116</b>	<b>N23116</b>	
--------------	---------------	--
- Century (2003 & Earlier)**  

<b>23084</b>	<b>N23084</b>	
--------------	---------------	--

**DOOR HANDLE TRIMS / LOGO TRIMS**  
Fits Classic, FLD, Century/Columbia. (Pair)

- 5 - With Flames**  

<b>20459</b>	<b>N20459</b>	
--------------	---------------	--
- Blank**  

<b>23090</b>	<b>N23090</b>	
--------------	---------------	--
- Logo Trims, Blank**  

<b>23113</b>	<b>N23113</b>	
--------------	---------------	--
- 6 - Logo Trims, with Flames**  

<b>23114</b>	<b>N23114</b>	
--------------	---------------	--

**CENTURY / COLUMBIA CAB PANELS**  
Mounts to bottom of door. (Pair)

Blank (0)	<b>26530</b>	<b>N26530</b>
<b>7 - Supernova (6)</b>	<b>26531</b>	<b>N26531</b>
Crew (6)	<b>26533</b>	<b>N26533</b>
2" Round Flat (8)	<b>26534B</b>	<b>N26534B</b>
2" Round Beehive (8)	<b>26535B</b>	<b>N26535B</b>
Challenger (8)	<b>26539B</b>	<b>N26539B</b>
Bulls-Eye (8)	<b>26540B</b>	<b>N26540B</b>
3/4" Button (8)	<b>26540GB</b>	<b>N26540GB</b>
Fusion (8)	<b>26541BC</b>	<b>N26541BC</b>
M1 (6)	<b>26531M1</b>	<b>N26531M1</b>
M3 (8)	<b>26534M3</b>	<b>N26534M3</b>
M5 (8)	<b>26539M5</b>	<b>N26539M5</b>
Mini (8)	<b>26539MN</b>	<b>N26539MN</b>

**CENTURY LOWER GRILLE INSERT**  
Fits Century, Columbia and FLD. (Each)

- Lower Grille Flames Insert  
**G. 23138**      **N23138**



See page 37 for Century/Columbia Sleeper Panels.



**N** \*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.