

# INDEX

## WESTERN STAR

### DROP VISORS

|   |     |
|---|-----|
| Standard Mount for Trucks with Cab Mounted Mirrors  | 264 |
| Standard Mount for Trucks with Door Mounted Mirrors | 264 |
| Blind Mount for Trucks with Cab Mounted Mirrors     | 265 |
| Blind Mount for Trucks with Door Mounted Mirrors    | 265 |

### FRONT END ACCESSORIES

|  |     |
|--|-----|
| Headlight Visors   | 266 |
| Tow Pin Covers   | 266 |
| Side Grille Air Deflectors                               | 266 |
| Lowmax Solid Mount Fender Guards                         | 266 |
| 4900EX Long Hood Punched Grille Insert                   | 267 |
| 32" Vertical Grille Bars                                 | 267 |
| 40.5" Horizontal Grille Bars                             | 267 |
| 4900EX Lowmax Punched Grille Insert                      | 267 |
| 28.5" Vertical Grille Bars                               | 267 |
| 40.5" Horizontal Grille Bars                             | 267 |
| 4900FA Short Hood Punched Grille Inserts                 | 267 |
| 28" Vertical Grille Bars                                 | 267 |
| 41" Horizontal Grille Bars                               | 267 |
| "Classic" - Std Mount 4900 Series Bumpers (07 & Earlier) | 269 |
| "Classic" - Std Mount 4900 Series Bumpers (08 & Newer)   | 269 |
| Standard Mount 4900 Series Bumpers (2007 & Earlier)      | 269 |
| Blind Mount 4900 Series Bumpers (2007 & Earlier)         | 269 |
| Standard Mount 4900 Series Bumpers (2008 & Newer)        | 269 |
| Blind 4900 Series Bumpers (2008 & Newer)                 | 269 |
| Multi-Fit Blind Mount Bumpers                            | 269 |

### BREATHER LIGHTS AND SCREENS

|  |     |
|--|-----|
| Donaldson Front Breather Lights - Long Hood  | 270 |
| Donaldson Front Breather Lights - Short Hood | 270 |
| Punched Breather Screens                     | 270 |
| Replacement Front Donaldson Breather Lights  | 270 |
| Replacement Rear Donaldson Breather Lights   | 270 |
| Replacement Front Nelson Breather Lights     | 270 |
| Replacement Rear Nelson Breather Lights      | 270 |

### SIDE HOOD AND CAB TRIMS AND ACCESSORIES

|   |     |
|---|-----|
| Hood Latch Trim                                 | 271 |
| Top of Hood Strap Pull Trim                     | 271 |
| Door Latch Trims                                | 271 |
| View Window Trims                               | 271 |
| Hood Logo Trims                                 | 271 |
| Top of Door "Chopped Look" Trims                | 272 |
| Lowmax Cowl Panels                              | 272 |
| Constellation Cowl Panels                       | 272 |
| Constellation / Lowmax Cab Panels               | 272 |
| Hood Extension Panels                           | 272 |
| Front of Door Trim with Mirror Bracket Holes    | 273 |
| Front of Door Trim without Mirror Bracket Holes | 273 |
| Upper Door Under Window Trims                   | 273 |
| Under Door Panels                               | 273 |
| Side of Cab Grab Handle Trims                   | 275 |

### BATTERY / TOOL BOX / STEP TRIMS

|   |     |
|---|-----|
| 48.5" Strapped Battery, Tool Box Cover            | 275 |
| Side Covers for Strapped Lid Battery/Tool Box     | 275 |
| 48.5" Replacement Battery / Tool Box Top and Door | 275 |
| 47.5" Replacement Step                            | 275 |

## WESTERN STAR

### SLEEPER / FUEL TANK FAIRING / REAR ACCESSORIES

|                                 |     |
|---------------------------------|-----|
| Deck Plates                     | 274 |
| Rear Center Panels              | 274 |
| Rear Light Bars                 | 274 |
| 62" Lowmax Sleeper Panels       | 276 |
| 76" Stratoshpere Sleeper Panels | 276 |
| 68.75" Fuel Tank Fairings       | 276 |
| Sleeper Roof Trims              | 277 |
| Rear Window Shades - 9 Louver   | 277 |
| Rear Drop Visors                | 277 |
| Starlight Rear Vertical Bars    | 277 |

## VOLVO

### VN AND VT DROP VISORS

|  |     |
|--|-----|
| 17" Blind Mount Drop Visor               | 278 |
| 15" Blind Mount Drop Visor               | 278 |
| Blind Mount Monster Drop Bow-Tie Visor   | 278 |
| Blind Mount Regular Drop Bow-Tie Visor   | 278 |
| 17" Regular Mount Drop Visor             | 278 |
| 15" Regular Mount Drop Visor             | 278 |
| Regular Mount Monster Drop Bow-Tie Visor | 278 |
| Regular Mount Regular Drop Bow-Tie Visor | 278 |

### VT 880 ACCESSORIES

|                          |     |
|--------------------------|-----|
| Punched Grille Inserts   | 279 |
| Punched Bumper Screens   | 279 |
| Inner Fender Trims       | 279 |
| Below Headlight Trims    | 279 |
| Side Hood Stripe         | 279 |
| Punched Intake Screens   | 279 |
| Cab and Cowl             | 280 |
| Sleeper Panels           | 280 |
| Lower Sleeper Window     | 280 |
| Upper Sleeper Window     | 280 |
| Cab Door Handle Surround | 280 |
| Sleeper Turn Light Trim  | 280 |

### VN GENERATION 2 ACCESSORIES

|                                    |     |
|------------------------------------|-----|
| Louvered Replacement Grille        | 281 |
| Side of Hood Behind Headlight Trim | 281 |
| Inner Fender Trim                  | 281 |
| Punched Intake Screen              | 281 |
| Cab Panels                         | 282 |
| Sleeper Panels                     | 282 |
| Replacement Steps                  | 282 |
| Door Handle Trims                  | 282 |

### VN GENERATION 2 ACCESSORIES

|                               |     |
|-------------------------------|-----|
| Under Cab Door Scuff Kit      | 283 |
| Front Upper Fairing Trim      | 283 |
| Front Scuff Kit Between Steps | 283 |
| Front Lower Fairing Trim      | 283 |