



ABOVE DOOR TRIMS (Pair)

- E. 1 - Tape Mount (Rear Stack) [2003 & Earlier]**

23077-11	N23077-11
-----------------	------------------

 (Side Stack)

23177-11	N23177-11
-----------------	------------------
- F. 1 - Tape Mount (Rear Stack) [2003 & Earlier]**

23080	N23080
--------------	---------------

 (Side Stack)

23180	N23180
--------------	---------------

CENTURY / COLUMBIA TOP OF DOOR TRIMS
Chopped look. (Pair)

POLISHED FINISH

- 2 - 6" - Top of Door Trim**

23020	N23020
--------------	---------------
- 7" - Top of Door Trim**

23022	N23022
--------------	---------------

SANDED FINISH

- 6" - Top of Door Trim**

23021	N23021
--------------	---------------
- 7" - Top of Door Trim**

23023	N23023
--------------	---------------

UNDER WINDOW TRIMS (Pair)

- 3 - Side Door Accents**

23085	N23085
--------------	---------------

SIDE COWL TRIMS (Pair)

- 4 - Columbia (2003 & Earlier)**

23116	N23116
--------------	---------------

 Century (2003 & Earlier)

23084	N23084
--------------	---------------

DOOR HANDLE TRIMS / LOGO TRIMS
Fits Classic, FLD, Century/Columbia. (Pair)

- 5 - With Flames**

20459	N20459
--------------	---------------

 Blank

23090	N23090
--------------	---------------

 Logo Trims, Blank

23113	N23113
--------------	---------------
- 6 - Logo Trims, with Flames**

23114	N23114
--------------	---------------

CENTURY / COLUMBIA CAB PANELS
Mounts to bottom of door. (Pair)

- | | | |
|--------------------------|----------------|-----------------|
| Blank (0) | 26530 | N26530 |
| 7 - Supernova (6) | 26531 | N26531 |
| Crew (6) | 26533 | N26533 |
| 2" Round Flat (8) | 26534B | N26534B |
| 2" Round Beehive (8) | 26535B | N26535B |
| Challenger (8) | 26539B | N26539B |
| Bulls-Eye (8) | 26540B | N26540B |
| 3/4" Button (8) | 26540GB | N26540GB |
| Fusion (8) | 26541BC | N26541BC |
| M1 (6) | 26531M1 | N26531M1 |
| M3 (8) | 26534M3 | N26534M3 |
| M5 (8) | 26539M5 | N26539M5 |
| Mini (8) | 26539MN | N26539MN |

CENTURY LOWER GRILLE INSERT
Fits Century, Columbia and FLD. (Each)

- Lower Grille Flames Insert
G. 23138 **N23138**



See page 41 for Century/Columbia Sleeper Panels.



*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.