

CASCADIA STANDARD MOUNT VISOR

Fits Mid and High Roof Cascadias. Does not fit Daycab. For trucks with no factory visor. Call RoadWorks Customer Service at 1-800-448-8741 for factory visor replacement. [2008 & Newer] (Kit)

Blank (0)	28000	N28000
Supernova (8)	28001	N28001
Crew (8)	28003	N28003
Challenger (10)	28009B	N28009B
Bulls-Eye (10)	28010B	N28010B
Bulls-Eye (10) ID-Pattern	28010BID	N28010BID
3/4" Button (10)	28010GB	N28010BB
Fusion (10)	28011BC	N28011BC
M1 (8)	28001M1	N28001M1
M3 (10)	28004M3	N28004M3
M5 (10)	28009M5	N28009M5
A. Mini (10)	28009MN	N28009MN

CASCADIA STANDARD MOUNT VISOR

Fits Cascadia Daycab. For trucks with factory visor. [2008 - 2017] (Kit)

Blank (0)	28040	N28040
Supernova (8)	28041	N28041
Crew (8)	28043	N28043
Challenger (10)	28049B	N28049B
Bulls-Eye (10)	28050B	N28050B
Bulls-Eye (10) ID-Pattern	28050BID	N28050BID
3/4" Button (10)	28050GB	N28050BB
Fusion (10)	28051BC	N28051BC
M1 (8)	28041M1	N28041M1
M3 (10)	28044M3	N28044M3
M5 (10)	28049M5	N28049M5
Mini (10)	28049MN	N28049MN

CASCADIA STANDARD MOUNT BRACKET KIT

Fits Cascadia Daycab. For trucks with factory visor. [2008 - 2017] (Kit)

Bracket Kit	28040-05	N28040-05
-------------	----------	-----------

CASCADIA BLIND MOUNT VISOR

Fits Cascadia Daycab. For trucks with factory visor. [2008 - 2017] (Kit)

Blank (0)	28060	N28060
Supernova (8)	28061	N28061
Crew (8)	28063	N28063
Challenger (10)	28069B	N28069B
Bulls-Eye (10)	28070B	N28070B
Bulls-Eye (10) ID-Pattern	28070BID	N28070BID
3/4" Button (10)	28070GB	N28070BB
Fusion (10)	28071BC	N28071BC
M1 (8)	28061M1	N28061M1
M3 (10)	28064M3	N28064M3
M5 (10)	28069M5	N28069M5
B. Mini (10)	28069MN	N28069MN

CASCADIA BLIND MOUNT BRACKET KIT

Fits Cascadia Daycab. For trucks with factory visor. [2008 - 2017] (Kit)

Bracket Kit	28060-05	N28060-05
-------------	----------	-----------

CASCADIA FRONT BUMPER, HEADLIGHT, AND FENDER TRIMS

For Long Hood Cascadias. [2008 & Newer]

Bumper Upper Middle Trim (Each)	28100	N28100
Bumper Upper Corner Trims (Pair)	28101	N28101
Under Headlight Trims (Pair)	28102	N28102
C. 1 - Bumper Side Trim (Pair)	28103	N28103
2 - Fender Outer Trims (Pair)	28104	N28104



To keep your equipment looking great use RoadWorks Detail Products, seen on pages 314-317.