



SLEEPER LOWER INSET TRIM
(Each)

- D. 1 - Lower Sleeper Inset Trim**
28120 N28120

SLEEPER UPPER INSET TRIM
(Pair)

- 2 - Upper Sleeper Inset Trims**
28121 N28121

SLEEPER VENT SURROUND
(Pair)

- 3 - Sleeper Vent Trims**
28122 N28122

72" SLEEPER + EXTENSION (Pair)

Does not fit Evolution.

Blank (0)	28700	N28700
Supernova (12)	28701	N28701
Crew (12)	28703	N28703
Challenger (20)	28709B	N28709B
3/4" Button (20)	28710G	N28710G
Fusion (20)	28711BC	N28711BC
M1 (12)	28701M1	N28701M1
M3 (20)	28704M3	N28704M3
M5 (20)	28709M5	N28709M5
E. Mini (20)	28709MN	N28709MN



For information about other Cascadia Sleeper sizes, Call RoadWorks Customer Service at 1-800-448-8741.

Call RoadWorks Customer Service at 1-800-448-8741 for information about Cascadia Sleeper Panels for sleepers with no Extensions.