



FLA EXTERIOR SLEEPER TRIMS

- E. 1 - Vent Trim Ring With Dimples (Each)**
20101 N20101

2 - Vent Cover With Sides
 4.25" X 8.5" (Each)
20097 N20097

 Vent Cover And Surround
 Kit contains both 20097 and 20101. (Kit)
20097-02 N20097-02

WINDOW AIR DEFLECTORS
 (Pair)

- 3 - Fits Classic, FLD, FLA and Fla.**
20430 N20430

UNDER WINDOW TRIMS
 (Pair)

- 4 - Door mounted mirrors**
20147 N20147

 Cab mounted mirrors
20148 N20148

DOOR LATCH TRIMS
 (Pair)

- 5 - Blank**
23090 N23090

 With Flames
20459 N20459

BELOW DOOR STEP TRIM
 (Kit)

- 6 - Fla Below Door Step Trim (4-piece kit)**
20116 N20116

GRAB HANDLE TRIMS
 (Sold as 8 pc kit)

- 7 - Entry Grab Handle Trims**
20098 N20098



KICK PANEL
 (Pair)

- F. 1 - Top Step Kick Panel**
20117 N20117

FLA CAB PANELS

- 2 - Please call **RoadWorks** customer service for different cab panel sizes at 1-800-448-8741.**

To keep your equipment looking great use RoadWorks Detail Products, seen on pages 314-317.

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.