

When replacing factory fiberglass visor, existing holes will not be reused. Factory Fiberglass Visor Bracket Locations will be visible.

MULTI-FIT ULTRACAB AND FLAT TOP BLIND MOUNT VISORS - Fits 357, 367, 377, 378, 379, 384, 385, 386, 388 and 389. (Kit)

CAB MOUNTED MIRRORS [2005 & Newer]
Does not fit 2014 & Newer "Pride and Class" edition
388 / 389 trucks.

14" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

A. Blank (0)	35075	N35075
3/4 Button (10)	35075LT0	N35075LT0
Bulls-Eye (10)	35075LT1	N35075LT1

BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

C. Monster Drop Bow-Tie	35076	N35076
--------------------------------	--------------	---------------

11" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

Blank (0)	35077	N35077
3/4 Button (10)	35077LT0	N35077LT0
Bulls-Eye (10)	35077LT1	N35077LT1

BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

D. Regular Drop Bow-Tie Visor	35078	N35078
--------------------------------------	--------------	---------------

BLIND MOUNT SUPER UN-TIE DROP VISOR [Kit]

Super Un-Tie Drop Visor	35085	N35085
-------------------------	--------------	---------------

See pages 56 - 58 for Pride and Class Edition Drop Visors [2014 & Newer]

MULTI-FIT VISORS FOR DOOR MOUNTED MIRRORS [1988 - 2005]

14" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

Blank (0)	35070	N35070
3/4 Button (10)	35070LT0	N35070LT0
Bulls-Eye (10)	35070LT1	N35070LT1

BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

Monster Drop Bow-Tie	35071	N35071
----------------------	--------------	---------------

11" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

Blank (0)	35072	N35072
3/4 Button (10)	35072LT0	N35072LT0
Bulls-Eye (10)	35072LT1	N35072LT1

BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

Regular Drop Bow-Tie Visor	35073	N35073
----------------------------	--------------	---------------

BLIND MOUNT SUPER UN-TIE DROP VISOR [Kit]

E. Super Un-Tie Drop Visor	35080	N35080
-----------------------------------	--------------	---------------

