



BLIND MOUNT UN-TIE DARWIN VISOR
 Fits 325, 330, 335, 337, 340, 347, 348, 357, 365, 367, 375, 377, 378, 379, 382, 384, 385, 386, 388 and 389. Fits UltraCab and Flat Top. Does not fit 2014 & Newer "Pride and Class" edition 388 / 389 trucks. (Kit)

See pages 66 - 68 for Pride and Class Edition Drop Visors [2014 & Newer]

CAB MOUNTED MIRRORS [2005 & Newer]

DARWIN 10.5" TO 6" UN-TIE VISOR [Kit]

| | | | |
|-----------|-----------------|-----------------|------------------|
| H. | Blank (0) | 35575 | N35575 |
| | Front Lights | | |
| | 3/4 Button (10) | 35575LT0 | N35575LT0 |
| | Front Lights | | |
| | Bulls-Eye (10) | 35575LT1 | N35575LT1 |
| | Top Lights | | |
| | 3/4 Button (10) | 35575LT2 | N35575LT2 |
| | Top Lights | | |
| I. | Bulls-Eye (10) | 35575LT3 | N35575LT3 |

DOOR MOUNTED MIRRORS [2004 & Earlier]

DARWIN 10.5" TO 6" UN-TIE VISOR [Kit]

| | | | |
|-----------|-----------------|-----------------|------------------|
| J. | Blank (0) | 35585 | N35585 |
| | Front Lights | | |
| | 3/4 Button (10) | 35585LT0 | N35585LT0 |
| | Front Lights | | |
| | Bulls-Eye (10) | 35585LT1 | N35585LT1 |
| | Top Lights | | |
| | 3/4 Button (10) | 35585LT2 | N35585LT2 |
| | Top Lights | | |
| K. | Bulls-Eye (10) | 35585LT3 | N35585LT3 |

CAB AND DOOR MOUNTED MIRRORS

Fits both cab and door mounted mirror trucks. [1988 & Newer]

See Image L for side view.

DARWIN 10.5" TO 6" UN-TIE VISOR [Kit]

| | | | |
|--|-----------------|-----------------|------------------|
| | Blank (0) | 35589 | N35589 |
| | Front Lights | | |
| | 3/4 Button (10) | 35589LT0 | N35589LT0 |
| | Front Lights | | |
| | Bulls-Eye (10) | 35589LT1 | N35589LT1 |
| | Top Lights | | |
| | 3/4 Button (10) | 35589LT2 | N35589LT2 |
| | Top Lights | | |
| | Bulls-Eye (10) | 35589LT3 | N35589LT3 |

For example images of Darwin Visors with lights on front surface see pages 71 - 72.

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.