

PETERBILT

POST MOUNT DARWIN VISORS - FOR 2 PIECE FLAT WINDSHIELDS

ULTRACAB AND FLAT TOP POST MOUNT DARWIN VISORS

When replacing factory fiberglass visor, existing holes will not be reused. Factory Fiberglass Visor Bracket Locations will be visible.

CAB MOUNTED MIRRORS [2005 & newer]
Visor mounts to center windshield post and to the two rivet positions below the mirror brackets on each side of the windshield. Side of visor is cut out for factory mirror brackets and does not require removal of mirror brackets for installation. Does not reuse any factory visor mount locations.
Visor will not conceal mounting locations from factory visor. Mounting hardware not included. Does not fit cabs with 1 piece curved windshields. (Sold as a kit)



POST MOUNT DARWIN UN-TIE VISOR [Kit]

A. Blank (0)	35912	N35912
Front Lights		
3/4 Button (10)	35912LT0	N35912LT0
Front Lights		
B. Bulls-Eye (10)	35912LT1	N35912LT1
Top Lights		
3/4 Button (10)	35912LT2	N35912LT2
Top Lights		
C. Bulls-Eye (10)	35912LT3	N35912LT3



Front Facing Peterbilt Lighted Visors end with LTO and LT1. Example: 35910LT1

Top Facing Peterbilt Lighted Visors end with LT2 and LT3. Example: 35910LT3

POST MOUNT DARWIN TOP-TIE VISOR [Kit]

D. Darwin Top-Tie Visor	35913	N35913
--------------------------------	--------------	---------------



DOOR MOUNTED MIRRORS [1987 - 2005]
Visor mounts to center windshield post and to the four rivet positions on outer cab posts. Does not reuse any factory visor mount locations.
Visor will not conceal mounting locations from factory visor. Mounting hardware not included. Does not fit cabs with 1 piece curved windshields. (Sold as a kit)

Post Mount 11.5" Darwin Drop Visor		
Blank (0)	35900	N35900
Post Mount 11.5" Darwin Drop Visor with Front		
3/4 Button (10)	35900LT0	N35900LT0
Post Mount 11.5" Darwin Drop Visor with Front		
Bulls-Eye (10)	35900LT1	N35900LT1
Post Mount 11.5" Darwin Drop Visor with Top		
3/4 Button (10)	35900LT2	N35900LT2
Post Mount 11.5" Darwin Drop Visor with Top		
Bulls-Eye (10)	35900LT3	N35900LT3



Post Mount Darwin Bow-Tie		
35901	N35901	

Post Mount Darwin Un-Tie Visor		
Blank (0)	35902	N35902
Post Mount Darwin Un-Tie Visor with Front		
3/4 Button (10)	35902LT0	N35902LT0
Post Mount Darwin Un-Tie Visor with Front		
Bulls-Eye (10)	35902LT1	N35902LT1
Post Mount Darwin Un-Tie Visor with Top		
3/4 Button (10)	35902LT2	N35902LT2
Post Mount Darwin Un-Tie Visor with Top		
Bulls-Eye (10)	35902LT3	N35902LT3

Post Mount Darwin Top-Tie Visor		
35903	N35903	

Does not require removal of factory mirror brackets for installation.

