

359 VISORS

359 STANDARD MOUNT VISORS

Also fits 340, 348, 349, 358 and 359. [1973-1987] (Kit)

13" Drop Visor

35041 N35041

Monster Drop Bow-Tie Visor

35043 N35043

11" Drop Visor

35040 N35040

Old School Bow-Tie Visor

35042 N35042

359 BLIND MOUNT VISORS (Kit)

13" BLIND MOUNT DROP VISORS [Kit]

- A.** Blank (0) **35046 N35046**
- 3/4 Button (10) **35046LT0 N35046LT0**
- B.** Bulls-Eye (10) **35046LT1 N35046LT1**

MONSTER DROP BOW-TIE VISOR [Kit]

Monster Drop Bow-Tie Visor **35049 N35049**

11" BLIND MOUNT DROP VISORS [Kit]

- C.** Blank (0) **35045 N35045**
- D.** 3/4 Button (10) **35045LT0 N35045LT0**
- Bulls-Eye (10) **35045LT1 N35045LT1**

REGULAR DROP BOW-TIE VISOR [Kit]

Regular Drop Bow-Tie Visor **35048 N35048**

OLD SCHOOL BOW-TIE VISOR [Kit]

- E.** Old School Bow-Tie Visor **35047 N35047**



[1973 & Newer] 359 Factory Bracket Locations

OLD SCHOOL BLIND MOUNT VISORS (Kit)

When replacing factory fiberglass visor, existing holes will not be reused. Factory Fiberglass Visor Bracket Locations will Be visible.

CAB AND DOOR MOUNTED MIRRORS

Fits 330, 335, 340, 357, 365, 367, 377, 378, 379, 384, 385, 386, 388, and 389. [1988-2014]

- F.** Old School Blind Mount Bow-Tie **35600 N35600**

CAB MOUNTED MIRRORS

Fits 330, 335, 340, 357, 365, 367, 378, 379, 384, 385, 386, 388, and 389. [2005-2013]

- G.** Old School Blind Mount Bow-Tie **35601 N35601**

DOOR MOUNTED MIRRORS - Fits 330, 357, 377, 378, 379, and 385. [2004 & Earlier]

- Old School Blind Mount Bow-Tie **35602 N35602**

