

Please call **RoadWorks** customer service at 1-800-448-8741 for more information or to enquire about earlier model curved windshield truck visors.

### BLIND MOUNT - CURVED WINDSHIELD DROP VISORS

**FLAT TOP / ULTA CAB 1 PIECE CURVED WINDSHIELD** Fits 365, 367, 384, 386, 388, 389 with Cab Mount Mirrors. [2011 & Newer] (Kit)

#### 13" BLIND MOUNT DROP VISOR [Kit]

<b>A.</b>	Blank (0)	<b>35650</b>	<b>N35650</b>
	3/4 Button (10)	<b>35650LT0</b>	<b>N35650LT0</b>
<b>B.</b>	Bulls-Eye (10)	<b>35650LT1</b>	<b>N35650LT1</b>

### BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

Monster Drop Bow-Tie	<b>35651</b>	<b>N35651</b>
----------------------	--------------	---------------

#### 10" BLIND MOUNT DROP VISOR [Kit]

<b>C.</b>	Blank (0)	<b>35652</b>	<b>N35652</b>
<b>D.</b>	3/4 Button (10)	<b>35652LT0</b>	<b>N35652LT0</b>
	Bulls-Eye (10)	<b>35652LT1</b>	<b>N35652LT1</b>

### BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

Regular Drop Bow-Tie Visor	<b>35653</b>	<b>N35653</b>
----------------------------	--------------	---------------

For Door Mount Mirrors on 2010 & Earlier call RoadWorks Customer Service at 1-800-448-8741.

### STANDARD MOUNT - CURVED WINDSHIELD DROP VISORS

**ULTRA CAB 1 PIECE CURVED WINDSHIELD** Fits 365, 367, 384, 386, 388, 389 with Cab Mount Mirrors. [2011 & Newer] (Kit)

<b>E.</b>	13" Drop Visor	<b>35665</b>	<b>N35665</b>
	Monster Drop Bow-Tie Visor	<b>35666</b>	<b>N35666</b>
<b>F.</b>	10" Drop Visor	<b>35667</b>	<b>N35667</b>
	Regular Drop Bow-Tie Visor	<b>35668</b>	<b>N35668</b>

**FLAT TOP 1 PIECE CURVED WINDSHIELD** Fits 325, 335, 365, 367, 384, 386, 388, 389 with Cab Mount Mirrors. [2011 & Newer] (Kit)

	13" Drop Visor	<b>35660</b>	<b>N35660</b>
	Monster Drop Bow-Tie Visor	<b>35661</b>	<b>N35661</b>
	10" Drop Visor	<b>35662</b>	<b>N35662</b>
	Regular Drop Bow-Tie Visor	<b>35663</b>	<b>N35663</b>

