

**PETERBILT DOOR PERMIT PANELS (Pair)**

14" Door Permit Panel  
Fits trucks with door mounted mirrors. [2005 & Earlier]

- A. 30060 N30060**

---

- 7.375" x 5.5" Door Permit Panel  
Fits trucks with cab mounted mirrors. [2005 & Earlier]
- 30066 N30066**



**PETERBILT FRONT CORNER DOOR / WINDOW TRIMS (Pair)**

Front Corner Door Window Trim  
Fits 335, 357, 378, 379 and 385. [2005]

- B. 30146 N30146**

---

- Front Corner Door Window Trim  
Fits trucks with sloped doors. [2006 & Newer]
- 30168 N30168**

**FLAT TOP CAB SLEEPER ROOF TOP TRIM**

63" Stand-Up Sleeper with Flat Top Cab (3-piece kit)  
**30161 N30161**

Center Only for 63" Stand-Up with Flat Top Cab  
**30160 N30160**

Sides Only for 63" Stand-Up with Flat Top Cab (Pair)  
**30161-11 N30161-11**

**ULTRA CAB SLEEPER ROOF TOP TRIM**

- C. 30163 N30163**

---

- 63" Stand-Up Sleeper With Ultra Cab (3-piece kit)  
Center Only for 63" Stand-Up with Ultra Cab  
**30162 N30162**

---

- Sides Only for 63" Stand-Up with Ultra Cab (Pair)  
**30163-11 N30163-11**

---

- 70" UltraCab Sleeper (3-piece kit)  
**30164 N30164**

---

- Center Only for 70" Stand-Up with Ultra Cab  
**30162 N30162**

---

- Sides Only for 70" Stand-Up with Ultra Cab (Pair)  
**30164-11 N30164-11**



**OVAL VIEW WINDOW TRIMS**

Fits 330, 357, 359, 377, 378, 379, 385 (all aluminum cabs).  
Will not fit 387. [2005 & Earlier] (Each)

With Flames

- D. 30150 N30150**

---

- Blank
- E. 30102 N30102**

**RECTANGULAR VIEW WINDOW TRIMS**  
[2005 & Newer] (Each)

With Flames

- F. 30151 N30151**

---

- Blank
- G. 30152 N30152**

