

PETERBILT DOOR PERMIT PANELS (Pair)

14" Door Permit Panel
Fits trucks with door mounted mirrors. [2005 & Earlier]

A. 30060 N30060

7.375" x 5.5" Door Permit Panel
Fits trucks with cab mounted mirrors. [2005 & Earlier]

30066 N30066

PETERBILT FRONT CORNER DOOR / WINDOW TRIMS (Pair)

Front Corner Door Window Trim
Fits 335, 357, 378, 379 and 385. [2005]

B. 30146 N30146

Front Corner Door Window Trim
Fits trucks with sloped doors. [2006 & Newer]

30168 N30168

FLAT TOP CAB SLEEPER ROOF TOP TRIM

63" Stand-Up Sleeper with Flat Top Cab (3-piece kit)

30161 N30161

Center Only for 63" Stand-Up with Flat Top Cab

30160 N30160

Sides Only for 63" Stand-Up with Flat Top Cab (Pair)

30161-11 N30161-11

ULTRA CAB SLEEPER ROOF TOP TRIM

63" Stand-Up Sleeper With Ultra Cab (3-piece kit)

C. 30163 N30163

Center Only for 63" Stand-Up with Ultra Cab

30162 N30162

Sides Only for 63" Stand-Up with Ultra Cab (Pair)

30163-11 N30163-11

70" UltraCab Sleeper (3-piece kit)

30164 N30164

Center Only for 70" Stand-Up with Ultra Cab

30162 N30162

Sides Only for 70" Stand-Up with Ultra Cab (Pair)

30164-11 N30164-11

OVAL VIEW WINDOW TRIMS

Fits 330, 357, 359, 377, 378, 379, 385 (all aluminum cabs).
Will not fit 387. [2005 & Earlier] (Each)

With Flames

D. 30150 N30150

Blank

E. 30102 N30102

RECTANGULAR VIEW WINDOW TRIMS

[2005 & Newer] (Each)

With Flames

F. 30151 N30151

Blank

G. 30152 N30152

