

KENWORTH

KENWORTH VISORS

CURVED WINDSHIELD - BLIND MOUNT

Trucks with Stainless Steel Mirror Brackets	176
Trucks with Cast Mirror Brackets	180

CURVED WINDSHIELD - STANDARD MOUNT

Trucks With Stainless Steel Mirror Brackets	177
Trucks With Cast Mirror Brackets	180

FLAT WINDSHIELD - BLIND MOUNT

Trucks with Stainless Steel Mirror Brackets	178
---	-----

FLAT WINDSHIELD - STANDARD MOUNT

Trucks with Stainless Steel Mirror Brackets	179
Trucks with Cast Mirror Brackets	179

REPLACEMENTS AND INSERTS

Replacement Visors for Curved and Flat Windshield Trucks	182
Fiberglass Visor Insert	182

K100 CABOVER

K100 Blind Mount 11" Drop Visor	182
---------------------------------	-----

W900A VISORS

Visors for W900A [1975 & Newer]	182
---------------------------------	-----

T680 / 880 VISORS

15.5" Blind Mount Visors with Lights	183
Un-Tie Blind Mount Visors with Lights	183
Replacement Drop Visors	183

KENWORTH GRILLE ACCESSORIES

Kenworth Style Grille Bars for W900L	184
Kenworth Style Grille Bars for W900B Short Hood	184
Kenworth Style Grille Bars for W900A	184
Kenworth Style Grille Bars for T800	184
Triple Diamond Punched Grille Insert W900L	185
Python Replacement Grille Insert W900L	185
Billet Style Grille Insert W900L, W900B, T800	185 - 188
W900L Extended Hood Replacement Grille Inserts	186
W900L Hood / Front Accessories	186
W900B Regular Hood Replacement Grille Inserts	187
W900B Hood / Front Accessories	187
T800 Python Grille Inserts	188
T800 Replacement Grille Inserts	188

W900 FENDER GUARDS / HOOD AND FRONT ACCESSORIES

W900 Fender Guards and Grille Trims	189
Side Signal Visors	189
Center Hood Trims	189
Headlight Visors	189
Upper Fender Guards	189

KENWORTH W900L / W900B BUMPERS

Standard Mount 16" Bumpers	191
Standard Mount 18" Bumpers	191
Standard Mount 20" Bumpers	191
Standard Mount 22" Bumpers	191
Blind Mount 16" Bumpers	191
Blind Mount 18" Bumpers	191
Blind Mount 20" Bumpers	191
Blind Mount 22" Bumpers	191
Multi-Fit Blind Mount Bumpers	191

W900 FENDER GUARDS / BUMPER ACCESSORIES

W900L Solid Mount Fender Guards	192
W900B Solid Mount Fender Guards	192
W900L Flat Style Fender Guards	192
W900L Fender Guards	192
Bumper Accessories	192

BREATHER ACCESSORIES

W900 Elephant Ears	192
Air Cleaner Blank	192
Front Breather Lights - 13" Diameter Vortex / Donaldson	193
Front Breather Lights - 15" Diameter Vortex	193
Front Breather Lights - 15" Diameter Premium / Regular Donaldson	193
Front Breather Lights - 15" Diameter Donaldson Preferred Fit	193
Rear Breather Lights - 13" Diameter Vortex / Donaldson	194
Rear Breather Lights - 15" Diameter Vortex	194
Rear Breather Lights - 15" Diameter Premium / Regular Donaldson	194
Rear Breather Lights - 15" Diameter Donaldson Preferred Fit	194
Inner Breather Lights - 15" Premium Donaldson	194
Inner Breather Lights - 15" Regular Donaldson	194
Inner Breather Lights - 15" Vortex Donaldson	194
Inner Breather Lights - 13" Regular Donaldson	194

HOOD AREA ACCESSORIES

Intake Panel	192
Hood Latch Trims and Hood Scoops	195
Side Hood and Logo Trims	195

SIDE CAB ACCESSORIES

Door Latch Trims	195
3" top of door "Chopped Look" Trim	196
6" top of door "Chopped Look" Trim	196
Under Window Trims	196

SIDE CAB ACCESSORIES

Side Window Air Deflectors	196
View Window Trims	196

KENWORTH

W900L / W900B / T800 KICK PANELS

W900L Aero Cab	197
W900L Non-Aero Cab	197
W900B Aero Cab	197
W900B Non-Aero Cab	197
Split Fender Aero Cab	197
Split Fender Non-Aero Cab	197
One Piece Aero Cab	197
One Piece Non-Aero Cab	197

CAB AND COWL PANELS / HOOD EXTENSIONS

T800 Split Fender Cab Panels With 3.5" Face	200
T800 One Piece Hood Cab Panels With 3.5" Face	200
T800 Split Fender Cab and Cowl Panels With 1.25" Face	200
T800 One Piece Hood Cab and Cowl Panels With 1.25" Face	200
W900L 51" Cab Panels With 3.5" Face	200
W900B 47" Cab Panels With 3.5" Face	200
W900L Lower Hood Extensions	201
W900L Cowl Extensions	201
W900B Hood Extensions	201
W900B Mock Cowl Extension	201
W900L Cab Panels With 1.25" Face	201
W900B Cab Panels With 1.25" Face	201
W900L Cowl Panels With 1.25" Face	201

BATTERY, TOOL BOX, DPF, DEF COVERS, FRAME STEPS

Battery and Tool Box Covers	202
50.75" DPF Replacement Cover and Step Kit	203
49.5" Battery Box Replacement Cover and Step Kit	203
DEF Tank Covers	203
Frame Rail Steps	202

FUEL TANK FAIRINGS

72.5" Fairings on 86" Studio Sleepers	204
72.5" Fairings on 72" and Smaller Sleepers	204
66" Fairings	204
60" Fairings	204
48" Fairings	204

SLEEPER PANELS FOR TRUCKS WITH NO DPF

86" Studio + Extension 3.5" Face	205
86" Studio No Extension 3.5" Face	205
72" Aero + Extension 3.5" Face	205
72" Aero No Extension 3.5" Face	205
62" Aero + Extension 3.5" Face	205

SLEEPER PANELS

FOR TRUCKS WITH NO DPF

62" Aero No Extension 3.5" Face	205
60" Box + Extensions 3.5" Face	205
60" Box No Extensions 3.5" Face	205
50" Box + Extensions 3.5" Face	205
50" Box No Extensions 3.5" Face	205
42" Box + Extensions 3.5" Face	205
42" Box No Extensions 3.5" Face	205
38" Aero + Extensions 3.5" Face	205
38" Aero No Extensions 3.5" Face	205

FOR TRUCKS WITH DPF

86" Studio + Extensions 3.5" Face	206
86" Studio No Extensions 3.5" Face	206
72" Aero + Extensions 3.5" Face	206
72" Aero No Extensions 3.5" Face	206
62" Aero + Extensions 3.5" Face	206
62" Aero No Extensions 3.5" Face	206
38" Aero + Extensions 3.5" Face	206
38" Aero No Extensions 3.5" Face	206

1.25" FACE SLEEPER PANELS

86" Studio + Extensions 1.25" Face	207
86" Studio No Extensions 1.25" Face	207
72" Aero + Extensions 1.25" Face	207
72" Aero No Extensions 1.25" Face	207
62" Aero + Extensions 1.25" Face	207
62" Aero No Extensions 1.25" Face	207
38" Aero + Extensions 1.25" Face	207
38" Aero No Extensions 1.25" Face	207

SLEEPER SIDE, TOP, AND REAR ACCESSORIES

Sleeper Window Trims	208
4.88" X 10.44" Vent Covers	208
4.75" X 10.25" Vent Covers	208
Sleeper Door Handle Trim	208
Inner Extension Rear Vertical Bars	209
Sleeper Roof Trims	209
Rear Window Drop Visors	209
Rear Window Louver Style Shade	209

K100 CABOVER ACCESSORIES

Drop Visor	228
Grille Inserts	228
Vent Trims	228
Door Handle Trims	228
Window Air Deflectors	229
Battery Box Covers	229
Tank Mounted Steps	229

T660 ACCESSORIES

Drop Visors	180, 230
Punched Grille Inserts	230
Punched Intake Screens	230

T660 CAB SIDE TRIMS

Top of Door Chopped Look Trims	231
Behind Grab Handle Trims	231
Door Latch Trims	231
View Window Trims	231
Kick Panels	231
Scuff Kits	231
Fender Signal Trims	231
Under Window Trims	231
Cab Panels	231
Hood Strap Trims	231

KENWORTH

T660 SLEEPER PANELS / SLEEPER ACCESSORIES

86" Sleeper + Extensions / 1.5" Face	232
86" Sleeper No Extensions / 1.5" Face	232
72" Sleeper + Extensions / 1.5" Face	232
72" Sleeper No Extensions / 1.5" Face	232
62" Sleeper + Extensions / 1.5" Face	232
62" Sleeper No Extensions / 1.5" Face	232
38" Sleeper + Extensions / 1.5" Face	232
38" Sleeper No Extensions / 1.5" Face	232
Studio Sleeper Trims	232

KENWORTH REAR FRAME ACCESSORIES

Rear Frame Covers	233
Rear Center Panels	233
Rear Cross Member Cover	233
Frame Step Trims	233
Frame Rail Steps	202
Mud Flap Accessories	233

T680 DROP VISORS

15.5" Blind Mount Drop Visors	210
Blind Mount Untie Drop Visors	210
11" Replacement Drop Visor	210
11" Outer, 8" Center Untie Drop Visor	210

T680 BUMPERS

3 Piece Blind Mount Replacement Bumper 17" Outer, 13.5" Center	211
--	-----

T680 GRILLE INSERTS AND ACCESSORIES

Replacement Grille Inserts 30 Horizontal Bars	212
Replacement Grille Inserts 30 Louver Style Bars	212
Punched Grille Inserts	212
Kenworth Style Vertical Grille Bars	212

T680 FRONT END / HOOD ACCESSORIES

Headlight Trims	215
Hood Strap Trims	215
Fender Side Marker Trim	216
Replacement Side Intake Screens	217
Fender Trims	216

T680 CAB SIDE ACCESSORIES

Chopped Look Top of Door Trims	216
Upper Door Under Window Trims	216
Cab Door Handle Trims	216
Door Logo Trims	216
Battery Box Cover and Steps [2013 & Newer]	217
DPF Cover and Steps [2013 & Newer]	217

T680 LOWER SIDE / SLEEPER / REAR ACCESSORIES

Sleeper Window Trims	218
DEF Filler Bezel Trim	218
Dimpled Back of Sleeper Center Bar Trims	219
Daycab and Sleeper Rear Window Trims	218
Load Light Trims	219
Cab Vent Covers	219
Cab Double Vent Covers	219
Vertical Grab Handle Trims	218
Sleeper Shock Covers	219
Sleeper Side Vent Covers and Trims	219
Dimpled Side Vent Surround	219
Replacement Tail Light Panel	219

T680 CAB PANELS

3" Face Cab Panels - No Stacks	221
3" Face Cab Panels - Passenger Side Stacks	221
3" Face Cab Panels - Dual Stacks	221
3" Face Daycab Cab Panels - No Stacks	221
3" Face Daycab Cab Panels - Passenger Side Stacks	221
3" Face Daycab Cab Panels - Dual Stacks	221

T680 SLEEPER PANELS

76" Sleeper Panels with Extensions High Slpr Roof Only	222
76" Sleeper Panels No Extensions High Slpr Roof Only	222
76" Sleeper Panels with Extensions No Stacks	222
76" Sleeper Panels No Extensions No Stacks	222
76" Sleeper Panels with Extensions Dual Stacks	222
76" Sleeper Panels No Extensions Dual Stacks	222
52" Sleeper Panels with Extensions Passenger Side Stack Only	223
52" Sleeper Panels No Extensions Passenger Side Stack Only	224
52" Sleeper Panels with Extensions No Stacks	223
52" Sleeper Panels No Extensions No Stacks	224
52" Sleeper Panels with Extensions Dual Stacks	223
52" Sleeper Panels No Extensions Dual Stacks	224
40" Sleeper Panels with Extensions Passenger Side Stack Only	225
40" Sleeper Panels No Extensions Passenger Side Stack Only	225
40" Sleeper Panels with Extensions No Stacks	225
40" Sleeper Panels No Extensions No Stacks	225
40" Sleeper Panels with Extensions Dual Stacks	225
40" Sleeper Panels No Extensions Dual Stacks	225

T880 DROP VISORS

15.5" Blind Mount Drop Visors	210
Blind Mount Untie Drop Visors	210
11" Replacement Drop Visor	210
11" Outer, 8" Center Untie Drop Visor	210

T880 BUMPERS

1 Piece Replacement 18"	211
3 Piece Replacement 18"	211
Under Bumper Bar for Tapered Bumper	211
Lower Fender Behind Bumper Trim	211

KENWORTH

T880 GRILLE INSERTS AND ACCESSORIES

Replacement Grille Inserts 26 Horizontal Bars	213
Replacement Grille Inserts 26 Louver Style Bars	213
Punched Grille Inserts	213
Kenworth Style Vertical Grille Bars	213

T880 FRONT END / HOOD ACCESSORIES

Fender Guards	215
Hood Strap Trims	215
Fender Side Marker Trim	216
Replacement Side Intake Screens	217
Fender Trims	216

T880 CAB SIDE ACCESSORIES

Chopped Look Top of Door Trims	216
Upper Door Under Window Trims	216
Cab Door Handle Trims	216
Door Logo Trims	216
Battery Box Cover and Steps [2013 & Newer]	217
DEF Covers	217
DPF Cover and Steps [2013 & Newer]	217

T880 LOWER SIDE / SLEEPER / REAR ACCESSORIES

Dimpled Back of Sleeper Center Bar Trims	219
Daycab Rear Window Trims	218
Sleeper Rear Window Trims	219
Load Light Trims	219
Cab Vent Covers	219
Cab Double Vent Covers	219
Daycab Vertical Grab Handle Trim	218
Vertical Grab Handle Trim	219
Sleeper Shock Covers	219
Sleeper Side Vent Covers and Trims	219
Dimpled Side Vent Surround	219
Replacement Tail Light Panel	219

T880 CAB PANELS / SLEEPER PANELS

3" Face Cab Panels - No Stacks	221
3" Face Cab Panels - Passenger Side Stacks	221
3" Face Cab Panels - Dual Stacks	221
3" Face Daycab Cab Panels - No Stacks	221
3" Face Daycab Cab Panels - Passenger Side Stacks	221
3" Face Daycab Cab Panels - Dual Stacks	221

T680 SLEEPER PANELS

76" Sleeper Panels with Extensions High Slpr Roof Only	222
76" Sleeper Panels No Extensions High Slpr Roof Only	222
76" Sleeper Panels with Extensions No Stacks	222
76" Sleeper Panels No Extensions No Stacks	222
76" Sleeper Panels with Extensions Dual Stacks	222
76" Sleeper Panels No Extensions Dual Stacks	222
52" Sleeper Panels with Extensions Passenger Side Stack Only	223
52" Sleeper Panels No Extensions Passenger Side Stack Only	224
52" Sleeper Panels with Extensions No Stacks	223
52" Sleeper Panels No Extensions No Stacks	224
52" Sleeper Panels with Extensions Dual Stacks	223
52" Sleeper Panels No Extensions Dual Stacks	224
40" Sleeper Panels with Extensions Passenger Side Stack Only	225
40" Sleeper Panels No Extensions Passenger Side Stack Only	225
40" Sleeper Panels with Extensions No Stacks	225
40" Sleeper Panels No Extensions No Stacks	225
40" Sleeper Panels with Extensions Dual Stacks	225
40" Sleeper Panels No Extensions Dual Stacks	225

T680 / T880 INTERIOR ACCESSORIES

Headliner Area Trims	226
Main Dash / Gauge Cluster Trims	226
Driver Side End Dash / Left and Right of Steering Colum	226
Top of Console Trims	226
Ignition Area Trims	226
Cab Door Handle Trims	227
Power Window Trims	227
Interior Cab Storage Door Covers	227
Cab Door Speaker Trims	227
Interior Sleeper Vent Trim	227
Shifter Boot Trim	227
Sleeper Control Panel Trim	227

KENWORTH INTERIOR ACCESSORIES

Driver Side Interior Trims	234
Passenger Side Interior Trims	234
Interior Trims [2002 - 2004]	234
Center Console Without Cutout for Power Mirror Controls	234
Center Console With Cutout for Power Mirror Controls	234
Headliner Trims [1995 - 2004]	235
Covers	235
Glove Box Trims	235
Interior Trims	236
Console Trims	236
Headliner Trims [2001 and Earlier]	236
Interior Trims [2008 and Newer]	237