



STANDARD MOUNT CURVED WINDSHIELD VISORS FOR TRUCKS WITH STAINLESS MIRROR BRACKETS

Fits Models W900B, W900L, T300, T400, T600 and T800. Must have stainless steel mirror brackets. Will not replace fiberglass visors. (Kit)

F. 13" Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45050 N45050

G. 13" Louvered Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45050L N45050L

H. Monster Drop Bow-Tie Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45051 N45051

I. 10" Drop Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45052 N45052

Regular Drop Bow-Tie Visor
Fits trucks with 3 factory brackets. [2006 & Earlier]
45053 N45053

13" Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45070 N45070


13" Louvered Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45070L N45070L

Monster Drop Bow-Tie Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45071 N45071


10" Drop Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45072 N45072

Regular Drop Bow-Tie Visor
Fits trucks with 2 factory brackets. [2007 & Newer]
45073 N45073


STANDARD STRAIGHT VISOR



UN-TIE VISOR



BOW-TIE VISOR



N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

Not sure which type of mirror you have? See these images for examples of cast mirror brackets and stainless mirror brackets.




Cast Mirror Bracket




Stainless Mirror Bracket

To order the Un-Tie version of any 13" or 10" Drop Visor on these 2 pages, add UT to the end of the regular part number between the numbers and any letters. Example: An Un-Tie Visor from image A above would be part number 45610UTB.

10 OR 13 INCH DROP VISOR PROFILE



UN-TIE VISOR PROFILE



See page 382 for information on ordering Millennium Glo Series lights on any RoadWorks lighted part.

STANDARD MOUNT VISORS FOR TRUCKS WITH CURVED WINDSHIELD AND STAINLESS STEEL MIRROR BRACKETS

Fits trucks with factory fiberglass visor or trucks without a factory visor.

13" DROP VISOR

Blank (0)	45640	N45640
SuperNova (6)	45641	N45641
Crew (6)	45643	N45643
2" Round Flat (10)	45644B	N45644B
2" Round Beehive (10)	45645B	N45645B
Challenger (10)	45649B	N45649B
Bulls-Eye (10)	45650B	N45650B
3/4" Button (10)	45650GB	N45650GB
Fusion (10)	45651BC	N45651BC
M1 (6)	45641M1	N45641M1
M3 (10)	45644M3	N45644M3
M5 (10)	45649M5	N45649M5
Mini (10)	45649MN	N45649MN

10" DROP VISOR

Blank (0)	45660	N45660
SuperNova (6)	45661	N45661
Crew (6)	45663	N45663
2" Round Flat (10)	45664B	N45664B
2" Round Beehive (10)	45665B	N45665B
Challenger (10)	45669B	N45669B
Bulls-Eye (10)	45670B	N45670B
3/4" Button (10)	45670GB	N45670GB
Fusion (10)	45671BC	N45671BC
M1 (6)	45661M1	N45661M1
M3 (10)	45664M3	N45664M3
M5 (10)	45669M5	N45669M5
Mini (10)	45669MN	N45669MN

BLIND MOUNT VISORS FOR TRUCKS WITH CURVED WINDSHIELD AND STAINLESS STEEL MIRROR BRACKETS

Fits trucks with factory fiberglass visor or trucks without a factory visor.

13" DROP VISOR

Blank (0)	45740	N45740
SuperNova (6)	45741	N45741
Crew (6)	45743	N45743
2" Round Flat (10)	45744B	N45744B
2" Round Beehive (10)	45745B	N45745B
Challenger (10)	45749B	N45749B
Bulls-Eye (10)	45750B	N45750B
3/4" Button (10)	45750GB	N45750GB
Fusion (10)	45751BC	N45751BC
M1 (6)	45741M1	N45741M1
M3 (10)	45744M3	N45744M3
M5 (10)	45749M5	N45749M5
Mini (10)	45749MN	N45749MN

10" DROP VISOR

Blank (0)	45720	N45720
SuperNova (6)	45721	N45721
Crew (6)	45723	N45723
2" Round Flat (10)	45724B	N45724B
2" Round Beehive (10)	45725B	N45725B
Challenger (10)	45729B	N45729B
Bulls-Eye (10)	45730B	N45730B
3/4" Button (10)	45730GB	N45730GB
Fusion (10)	45731BC	N45731BC
M1 (6)	45721M1	N45721M1
M3 (10)	45724M3	N45724M3
M5 (10)	45729M5	N45729M5
Mini (10)	45729MN	N45729MN

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.