



W900L AND W900B KICK PANELS

Covers the factory Kick Panels. 'Heater Plug' means hole is on the driver side. 'Step Lights' mean holes for factory step lights are on both panels. [1995 - 2008] (Pair)

For 2009 trucks call RoadWorks Customer Service at 1-800-448-8741

W900L AERO CAB

Without Plug, Without Light	40230	N40230
Heater Plug	40231	N40231
Plug and Light	40232	N40232
Step Light	40233	N40233

K.

W900L NON-AERO CAB

Without Plug, Without Light	40235	N40235
Heater Plug	40236	N40236
Plug and Light	40237	N40237
Step Light	40238	N40238

L.

W900B AERO CAB

Without Plug, Without Light	40220	N40220
Heater Plug	40221	N40221
Plug and Light	40222	N40222
Step Light	40223	N40223

W900B NON-AERO CAB

Without Plug, Without Light	40225	N40225
Heater Plug	40226	N40226
Plug and Light	40227	N40227
Step Light	40228	N40228

M.

T800 KICK PANELS

'Heater Plug' means hole is on the driver side. Covers the factory Kick Panels. 'Step Lights' mean holes for factory step lights are on both panels. [1995 & 2010] (Pair)



SPLIT FENDER AERO CAB

Without Plug, Without Light	40200	N40200
Heater Plug	40201	N40201
Plug and Light	40202	N40202
Step Light	40203	N40203

SPLIT FENDER NON-AERO CAB

Without Plug, Without Light	40205	N40205
Heater Plug	40206	N40206
Plug and Light	40207	N40207
Step Light	40208	N40208

N.

1 - PIECE AERO CAB

Without Plug, Without Light	40210	N40210
Heater Plug	40211	N40211
Plug and Light	40212	N40212
Step Light	40213	N40213

O.

1 - PIECE NON-AERO CAB

Without Plug, Without Light	40215	N40215
Heater Plug	40216	N40216
Plug and Light	40217	N40217
Step Light	40218	N40218



For trucks with DPF / DEF call RoadWorks Customer Service at 1-800-448-8741.

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

W900L REPLACEMENT KICK PANELS

Heater Plug' means hole is on the driver side. 'Step Lights' mean holes for factory step lights are on both panels. [2010 & Newer] (Pair)

W900L AERO CAB

Driver Side and Passenger Side Kick Panel Height 5 1/2".

A. Without Plug, Without Light	40240	N40240
Heater Plug	40241	N40241
Plug and Light	40242	N40242
Step Light	40243	N40243

See next page for image C for view of 40241.

W900L AERO CAB

Driver Side Kick Panel Height 5 1/2", Passenger Side Kick Panel Height 4 1/4".

B. Without Plug, Without Light	40245	N40245
Heater Plug	40246	N40246
Plug and Light	40247	N40247
Step Light	40248	N40248

