

### HI-RISE / SKY-RISE SLEEPER WINDOW TRIM (pair)

- A. 1 - On Glass Window Trim

51076 N51076

Window Surround Trim

51075 N51075

### HI RISE / SKY-RISE STORAGE DOOR TRIMS

- 2 - Storage Door Cover

51070 N51070

Diamond Lock Surround (Pair)

51060 N51060

### LT - PROSTAR - LONESTAR BUNK STORAGE DOOR HANDLE (Each)

Image on page 248

Bunk Storage Door Handle

51066 N51066

### REAR OF SLEEPER LETTER TRIM

- B. 1 - "International" Letters (Kit)

51089 N51089

- 2 - "International" Letter Surrounds (Each)

51088 N51088

- 3 - Back Of Sleeper Vent Trims

For LT fit call RoadWorks Customer Service (Pair)

51080 N51080

- 4 - Back Of Sleeper Load Light Trim

For LT fit call RoadWorks Customer Service (Each)

51081 N51081

Back Of Sleeper Trims, Driver Side Vent Hole

For LT fit call RoadWorks Customer Service (Pair)

51082 N51082

Back Of Sleeper Center Trim

For LT fit call RoadWorks Customer Service (Each)

51083 N51083

Back Of Sleeper Trims, Passenger Side Vent Hole

For LT fit call RoadWorks Customer Service (Pair)

51084 N51084

### AIR LINE / ELECTRICAL LINE BRACKET

Replaces Original Part. (Each)

- C. 51085 N51085



### LT - PROSTAR VISORS

#### 12.5" DROP VISORS FITS LT, LONESTAR AND PROSTAR WITH HI-RISE PRO SLEEPERS

Replaces factory fiberglass or stainless visor. For Sleeper Trucks Only. Add an "L" to your part number to have a louvered visor. (Kit)

See page 226 for Daycab Visors.

Blank (0)	55220	N55220
SuperNova (8)	55221	N55221
Crew (8)	55223	N55223
2" Round Flat (10)	55224B	N55224B
2" Round Beehive (10)	55225B	N55225B
Challenger (10)	55229B	N55229B
A. Bulls-Eye (10)	55230B	N55230B
Bulls-Eye (10) ID Pattern	55230BID	N55230BID
3/4" Button (10)	55230GB	N55230GB
Fusion (10)	55231BC	N55231BC
M1 (8)	55221M1	N55221M1
M3 (10)	55224M3	N55224M3
M5 (10)	55229M5	N55229M5
Mini (10)	55229MN	N55229MN



### LT - CAB DOOR TRIMS

**NEW**

- B. 1 - Top of Door Trims "Chop" (Pair)  
51067 N51067
- 
- 2 - Top of Door Under Window Trims (Pair)  
51061 N51061

### LT - UNDER HEADLIGHT TRIMS (Pair)

- C. Under Headlight Trims **NEW**  
51068 N51068



### LT - OUTSIDE FENDER TRIMS

For trucks without fairings. (4 Piece Kit)

- D. Outside Fender Trims **NEW**  
51069 N51069



### LT - BUMPER SCREEN (Each)

**NEW**

- E. Bumper Screen  
51093-XX N51093-XX

### PUNCH OPTIONS

View punch styles page 362.

-23	Small 1/4" Circles
-24	Large 7/16" Circles
-28	Hexagons
-30	Horizontal Rectangles
-31	Vertical Rectangles
-32	5/16" In-Line Squares
-33	5/16" Offset Squares
-36	Horizontal Oval Holes
-37	Vertical Ovals
-38	Horizontal 3/16" Oblong
-39	Vertical 3/16" Oblong
-40	Horizontal 5/16" Oblong
-41	Vertical 5/16" Oblong
-46	Stars
-47	Snake Skin





**LT - BATTERY BOX COVER (Kit)**

**F.** Battery Box Cover **NEW**  
**51077 N51077**

**LT - DPF COVER (Kit)**

**G.** DPF Cover **NEW**  
**51078 N51078**

**LT CAB PANELS WITH HEATER PLUG HOLE** **NEW**  
 Fits trucks without fairings.. (Kit)

<b>H.</b> Blank (0)	<b>56600</b>	<b>N56600</b>
SuperNova (5)	<b>56601</b>	<b>N56601</b>
Crew (5)	<b>56603</b>	<b>N56603</b>
2" Round Flat (7)	<b>56604B</b>	<b>N56604B</b>
2" Round Beehive (7)	<b>56605B</b>	<b>N56605B</b>
Challenger (7)	<b>56609B</b>	<b>N56609B</b>
Bulls-Eye (7)	<b>56610B</b>	<b>N56610B</b>
3/4" Button (7)	<b>56610GB</b>	<b>N56610GB</b>
Fusion (7)	<b>56611BC</b>	<b>N56611BC</b>
M1 (5)	<b>56601M1</b>	<b>N56601M1</b>
M3 (7)	<b>56604M3</b>	<b>N56604M3</b>
M5 (7)	<b>56609M5</b>	<b>N56609M5</b>
Mini (7)	<b>56609MN</b>	<b>N56609MN</b>



**LT CAB PANELS WITHOUT HEATER PLUG HOLE** **NEW**  
 Fits trucks without fairings.. (Kit)

Blank (0)	<b>56620</b>	<b>N56620</b>
SuperNova (6)	<b>56621</b>	<b>N56621</b>
Crew (6)	<b>56623</b>	<b>N56623</b>
2" Round Flat (8)	<b>56624B</b>	<b>N56624B</b>
2" Round Beehive (8)	<b>56625B</b>	<b>N56625B</b>
Challenger (8)	<b>56629B</b>	<b>N56629B</b>
Bulls-Eye (8)	<b>56630B</b>	<b>N56630B</b>
3/4" Button (8)	<b>56630GB</b>	<b>N56630GB</b>
Fusion (8)	<b>56631BC</b>	<b>N56631BC</b>
M1 (6)	<b>56621M1</b>	<b>N56621M1</b>
M3 (8)	<b>56624M3</b>	<b>N56624M3</b>
M5 (8)	<b>56629M5</b>	<b>N56629M5</b>
Mini (8)	<b>56629MN</b>	<b>N56629MN</b>



**LT 73" SLEEPER PANELS** **NEW**  
 For trucks without fairings. (Kit)

<b>I.</b> Blank (0)	<b>57200</b>	<b>N57200</b>
SuperNova (10)	<b>57201</b>	<b>N57201</b>
Crew (10)	<b>57203</b>	<b>N57203</b>
2" Round Flat (14)	<b>57204B</b>	<b>N57204B</b>
2" Round Beehive (14)	<b>57205B</b>	<b>N57205B</b>
Challenger (14)	<b>57209B</b>	<b>N57209B</b>
Bulls-Eye (14)	<b>57210B</b>	<b>N57210B</b>
3/4" Button (14)	<b>57210GB</b>	<b>N57210GB</b>
Fusion (14)	<b>57211BC</b>	<b>N57211BC</b>
M1 (10)	<b>57201M1</b>	<b>N57201M1</b>
M3 (14)	<b>57204M3</b>	<b>N57204M3</b>
M5 (14)	<b>57209M5</b>	<b>N57209M5</b>
Mini (14)	<b>57209MN</b>	<b>N57209MN</b>



**LT - LOGO TRIMS (Pair)** **NEW**

**J.** **1 - Frame Logo Trims** **51062 N51062**  
**2 - Pointed Logo Trims** **51063 N51063**  
**3 - Rounded Logo Trims** **51064 N51064**

**LT - PROSTAR - LONESTAR BUNK STORAGE DOOR HANDLE (Each)**

**K.** Bunk Storage Door Handle **NEW**  
**51066 N51066**



**N** \*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.