

# INDEX

## PETERBILT

### PETERBILT SLEEPER TRIMS AND ACCESSORIES

359 / 379 Vent Covers	109
377 Vent Covers	109
Rear Sleeper Window Drop Visors	110
Rear Sleeper Window Shades	110
Side of Sleeper Window Trims	111
Load Light Brackets	110
Sleeper Shock Absorber Covers	109
Sleeper Shock Air Bag Covers	112-115

### PETERBILT FUEL TANK TRIMS AND ACCESSORIES

Tank Saddle Covers - Mitered Profiles - 26" Diameter Fuel Tank	94, 122
Tank Saddle Covers - Curved Profiles - 26" Diameter Fuel Tank	94, 122
Top of Fuel Tank Bracket Cover - 26" Diameter Fuel Tank	94, 122
Top of Fuel Tank Bracket Cover with Bolt Cutout - 26" Fuel Tank	94, 122
67.4" Fuel Tank Fairings - 150 Gallon Fuel Tank	95
61.5" Fuel Tank Fairings - 135 Gallon Fuel Tank	95
Fuel Tank Dummy Straps - 26" Diameter Fuel Tank	118

### PETERBILT DEF TANK TRIMS AND ACCESSORIES

DEF Tank Covers - Large 27 Gallon	95
DEF Tank Covers - Medium 18 Gallon	95
DEF Tank Covers - Small 11.8 Gallon	95
DEF Tank Cap	95
DEF Tank Cover Grommet	95

### PETERBILT FRAME STEPS

Peterbilt Frame Steps	163
-----------------------	-----

## KENWORTH

### CURVED WINDSHIELD - BLIND MOUNT - VISORS

Trucks with Stainless Steel Mirror Brackets	164
Trucks with Cast Mirror Brackets	164

### CURVED WINDSHIELD - STANDARD MOUNT - VISORS

Trucks With Stainless Steel Mirror Brackets	165
Trucks With Cast Mirror Brackets	165

### FLAT WINDSHIELD - BLIND MOUNT - VISORS

Trucks with Stainless Steel Mirror Brackets	166
---	-----

### FLAT WINDSHIELD - STANDARD MOUNT - VISORS

Trucks with Stainless Steel Mirror Brackets	167
Trucks with Cast Mirror Brackets	167

### REPLACEMENTS AND INSERTS - VISORS

Replacement Visors for Curved and Flat Windshield Trucks	170
Fiberglass Visor Insert	170

## KENWORTH

### K100 CABOVER - VISORS

K100 Blind Mount 11" Drop Visor	170
---------------------------------	-----

### W900A - VISORS

Visors for W900A [1975 & Newer]	170
---------------------------------	-----

### T680 / 880 - VISORS

15.5" Blind Mount Visors with Lights	171
Un-Tie Blind Mount Visors with Lights	171
Replacement Drop Visors	171

### KENWORTH GRILLE ACCESSORIES

Kenworth Style Grille Bars for W900L	172
Kenworth Style Grille Bars for W900B Short Hood	172
Kenworth Style Grille Bars for W900A	172
Kenworth Style Grille Bars for T800	172
Triple Diamond Punched Grille Insert W900L	173
Python Replacement Grille Insert W900L	173
Billet Style Grille Insert W900L, W900B, T800	173 - 174
W900L Extended Hood Replacement Grille Inserts	174
W900L Hood / Front Accessories	174
W900B Regular Hood Replacement Grille Inserts	175
W900B Hood / Front Accessories	175
T800 Python Grille Inserts	176
T800 Replacement Grille Inserts	176

### W900 FENDER GUARDS / HOOD AND FRONT ACCESSORIES

W900 Fender Guards and Grille Trims	177
Side Signal Visors	177
Center Hood Trims	177
Headlight Visors	177
Upper Fender Guards	177

### KENWORTH W900L / W900B BUMPERS

Classic - Standard Mount 16" Bumpers	179
Classic - Standard Mount 18" Bumpers	179
Classic - Standard Mount 20" Bumpers	179
Classic - Standard Mount 22" Bumpers	179
Standard Mount 16" Bumpers	179
Standard Mount 18" Bumpers	179
Standard Mount 20" Bumpers	179
Standard Mount 22" Bumpers	179
Blind Mount 16" Bumpers	179
Blind Mount 18" Bumpers	179
Blind Mount 20" Bumpers	179
Blind Mount 22" Bumpers	179
Multi-Fit Blind Mount Bumpers	179

### W900 FENDER GUARDS / BUMPER ACCESSORIES

W900L Solid Mount Fender Guards	180
W900B Solid Mount Fender Guards	180
W900L Flat Style Fender Guards	180
W900L Fender Guards	180
Bumper Accessories	180

# INDEX

## KENWORTH

### BREATHER ACCESSORIES

Front Breather Lights - 13" Diameter Vortex / Donaldson	181
Front Breather Lights - 15" Diameter Vortex	181
Front Breather Lights - 15" Diameter Premium / Regular Donaldson	181
Front Breather Lights - 15" Diameter Donaldson Preferred Fit	181
Rear Breather Lights - 13" Diameter Vortex / Donaldson	182
Rear Breather Lights - 15" Diameter Vortex	182
Rear Breather Lights - 15" Diameter Premium / Regular Donaldson	182
Rear Breather Lights - 15" Diameter Donaldson Preferred Fit	182
Inner Breather Lights - 15" Premium Donaldson	182
Inner Breather Lights - 15" Regular Donaldson	182
Inner Breather Lights - 15" Vortex Donaldson	182
Inner Breather Lights - 13" Regular Donaldson	182
W900 Elephant Ears	180
Air Cleaner Blank	180

### HOOD AREA ACCESSORIES

Intake Panel	180
Hood Latch Trims and Hood Scoops	183
Side Hood and Logo Trims	183

### SIDE CAB ACCESSORIES

Door Latch Trims	183
3" top of door "Chopped Look" Trim	184
6" top of door "Chopped Look" Trim	184
Under Window Trims	185
Side Window Air Deflectors	185
View Window Trims	185

### W900L / W900B / T800 KICK PANELS

W900L Aero Cab Replacement Kick Panels	186
W900L Aero Cab	187
W900L Non-Aero Cab	187
W900B Aero Cab	187
W900B Non-Aero Cab	187
Split Fender Aero Cab	187
Split Fender Non-Aero Cab	187
One Piece Aero Cab	187
One Piece Non-Aero Cab	187

### CAB AND COWL PANELS / HOOD EXTENSIONS

T800 Split Fender Cab Panels With 3.5" Face	188
T800 One Piece Hood Cab Panels With 3.5" Face	188
T800 Split Fender Cab and Cowl Panels With 1.25" Face	188
T800 One Piece Hood Cab and Cowl Panels With 1.25" Face	188
W900L 51" Cab Panels With 3.5" Face	188
W900B 47" Cab Panels With 3.5" Face	188
W900L Lower Hood Extensions	189
W900L Cowl Extensions	189
W900B Hood Extensions	189
W900B Mock Cowl Extension	189
W900L Cab Panels With 1.25" Face	189
W900B Cab Panels With 1.25" Face	189
W900L Cowl Panels With 1.25" Face	189

### BATTERY, TOOL BOX, DPF, DEF COVERS, FRAME STEPS

Battery and Tool Box Covers	190
50.75" DPF Replacement Cover and Step Kit	190
49.5" Battery Box Replacement Cover and Step Kit	190

## KENWORTH

### BATTERY, TOOL BOX, DPF, DEF COVERS, FRAME STEPS

DEF Tank Covers	190
Frame Rail Steps	190

### FUEL TANK FAIRINGS

72.5" Fairings on 86" Studio Sleepers	192
72.5" Fairings on 72" and Smaller Sleepers	192
66" Fairings	192
60" Fairings	192
48" Fairings	192

### SLEEPER PANELS

#### FOR TRUCKS WITH NO DPF

86" Studio + Extension 3.5" Face	193
86" Studio No Extension 3.5" Face	193
72" Aero + Extension 3.5" Face	193
72" Aero No Extension 3.5" Face	193
62" Aero + Extension 3.5" Face	193
62" Aero No Extension 3.5" Face	193
60" Box + Extensions 3.5" Face	193
60" Box No Extensions 3.5" Face	193
50" Box + Extensions 3.5" Face	193
50" Box No Extensions 3.5" Face	193
42" Box + Extensions 3.5" Face	193
42" Box No Extensions 3.5" Face	193
38" Aero + Extensions 3.5" Face	193
38" Aero No Extensions 3.5" Face	193

#### FOR TRUCKS WITH DPF

86" Studio + Extensions 3.5" Face	194
86" Studio No Extensions 3.5" Face	194
72" Aero + Extensions 3.5" Face	194
72" Aero No Extensions 3.5" Face	194
62" Aero + Extensions 3.5" Face	194
62" Aero No Extensions 3.5" Face	194
38" Aero + Extensions 3.5" Face	194
38" Aero No Extensions 3.5" Face	194

### 1.25" FACE SLEEPER PANELS

86" Studio + Extensions 1.25" Face	195
86" Studio No Extensions 1.25" Face	195
72" Aero + Extensions 1.25" Face	195
72" Aero No Extensions 1.25" Face	195
62" Aero + Extensions 1.25" Face	195
62" Aero No Extensions 1.25" Face	195
38" Aero + Extensions 1.25" Face	195
38" Aero No Extensions 1.25" Face	195

### SLEEPER SIDE, TOP, AND REAR ACCESSORIES

Sleeper Window Trims	196
4.88" X 10.44" Vent Covers	196
4.75" X 10.25" Vent Covers	196
Sleeper Door Handle Trim	196
Inner Extension Rear Vertical Bars	197

# INDEX

## KENWORTH

### SLEEPER SIDE, TOP, AND REAR ACCESSORIES

Sleeper Roof Trims	197
Rear Window Drop Visors	197
Rear Window Louver Style Shade	197

### K100 CABOVER ACCESSORIES

Drop Visor	216
Grille Inserts	216
Vent Trims	216
Door Handle Trims	216
Window Air Deflectors	217
Battery Box Covers	217
Tank Mounted Steps	217

### T660 ACCESSORIES

Drop Visors	168, 218
Punched Grille Inserts	218
Punched Intake Screens	218
3 Piece Replacement Bumpers	218

### T660 CAB SIDE TRIMS

Top of Door Chopped Look Trims	219
Behind Grab Handle Trims	219
Door Latch Trims	219
View Window Trims	219
Kick Panels	219
Scuff Kits	219
Fender Signal Trims	219
Under Window Trims	219
Cab Panels	219
Hood Strap Trims	219

### T660 SLEEPER PANELS / SLEEPER ACCESSORIES

86" Sleeper + Extensions / 1.5" Face	220
86" Sleeper No Extensions / 1.5" Face	220
72" Sleeper + Extensions / 1.5" Face	220
72" Sleeper No Extensions / 1.5" Face	220
62" Sleeper + Extensions / 1.5" Face	220
62" Sleeper No Extensions / 1.5" Face	220
38" Sleeper + Extensions / 1.5" Face	220
38" Sleeper No Extensions / 1.5" Face	220
Studio Sleeper Trims	220

### KENWORTH REAR FRAME ACCESSORIES

Rear Frame Covers	221
Rear Center Panels	221
Rear Cross Member Cover	221
Frame Step Trims	221
Frame Rail Steps	221
Mud Flap Accessories	221

### T680 DROP VISORS

15.5" Blind Mount Drop Visors	198
Blind Mount Untie Drop Visors	198
11" Replacement Drop Visor	198
11" Outer, 8" Center Untie Drop Visor	198

## KENWORTH

### T680 BUMPERS

3 Piece Blind Mount Replacement Bumper 17" Outer, 13.5" Center	199
--	-----

### T680 GRILLE INSERTS AND ACCESSORIES

Replacement Grille Inserts 30 Horizontal Bars	200
Replacement Grille Inserts 30 Louver Style Bars	200
Punched Grille Inserts	200
Kenworth Style Vertical Grille Bars	200
Two Diamond Punched Grille Inserts	202
Billet Style Grille Inserts	202

### T680 FRONT END / HOOD ACCESSORIES

Headlight Trims	203
Hood Strap Trims	203
Fender Side Marker Trim	204
Replacement Side Intake Screens	205
Fender Trims	204

### T680 CAB SIDE ACCESSORIES

Chopped Look Top of Door Trims	204
Upper Door Under Window Trims	204
Cab Door Handle Trims	204
Door Logo Trims	204
Battery Box Cover and Steps [2013 & Newer]	205
DPF Cover and Steps [2013 & Newer]	205

### T680 LOWER SIDE / SLEEPER / REAR ACCESSORIES

Sleeper Window Trims	206
DEF Filler Bezel Trim	206
Dimpled Back of Sleeper Center Bar Trims	206
Daycab and Sleeper Rear Window Trims	206
Load Light Trims	207
Cab Vent Covers	207
Cab Double Vent Covers	207
Vertical Grab Handle Trims	207
Sleeper Shock Covers	207
Sleeper Side Vent Covers and Trims	207
Dimpled Side Vent Surround	207
Replacement Tail Light Panel	207

### T680 CAB PANELS

3" Face Cab Panels - No Stacks	209
3" Face Cab Panels - Passenger Side Stacks	209
3" Face Cab Panels - Dual Stacks	209
3" Face Daycab Cab Panels - No Stacks	209
3" Face Daycab Cab Panels - Passenger Side Stacks	209
3" Face Daycab Cab Panels - Dual Stacks	209

### T680 SLEEPER PANELS

76" Sleeper Panels with Extensions High Slpr Roof Only	210
76" Sleeper Panels No Extensions High Slpr Roof Only	210
76" Sleeper Panels with Extensions No Stacks	210
76" Sleeper Panels No Extensions No Stacks	210
76" Sleeper Panels with Extensions Dual Stacks	210
76" Sleeper Panels No Extensions Dual Stacks	210
52" Sleeper Panels with Extensions Passenger Side Stack Only	211
52" Sleeper Panels No Extensions Passenger Side Stack Only	212
52" Sleeper Panels with Extensions No Stacks	211
52" Sleeper Panels No Extensions No Stacks	212

# INDEX

## KENWORTH

### T680 SLEEPER PANELS

52" Sleeper Panels with Extensions Dual Stacks	211
52" Sleeper Panels No Extensions Dual Stacks	212
40" Sleeper Panels with Extensions Passenger Side Stack Only	213
40" Sleeper Panels No Extensions Passenger Side Stack Only	213
40" Sleeper Panels with Extensions No Stacks	213
40" Sleeper Panels No Extensions No Stacks	213
40" Sleeper Panels with Extensions Dual Stacks	213
40" Sleeper Panels No Extensions Dual Stacks	213

### T880 DROP VISORS

15.5" Blind Mount Drop Visors	198
Blind Mount Untie Drop Visors	198
11" Replacement Drop Visor	198
11" Outer, 8" Center Untie Drop Visor	198

### T880 BUMPERS

1 Piece Replacement 18"	199
3 Piece Replacement 18"	199
Under Bumper Bar for Tapered Bumper	199
Lower Fender Behind Bumper Trim	199

### T880 GRILLE INSERTS AND ACCESSORIES

Replacement Grille Inserts 26 Horizontal Bars	201
Replacement Grille Inserts 26 Louver Style Bars	201
Punched Grille Inserts	201
Kenworth Style Vertical Grille Bars	201
Two Diamond Punched Grille Inserts	202
Billet Style Grille Inserts	202

### T880 FRONT END / HOOD ACCESSORIES

Fender Guards	203
Hood Strap Trims	203
Fender Side Marker Trim	204
Replacement Side Intake Screens	205
Fender Trims	204

### T880 CAB SIDE ACCESSORIES

Chopped Look Top of Door Trims	204
Upper Door Under Window Trims	204
Cab Door Handle Trims	204
Door Logo Trims	204
Battery Box Cover and Steps [2013 & Newer]	205
DEF Covers	205
DPF Cover and Steps [2013 & Newer]	205

### T880 LOWER SIDE / SLEEPER / REAR ACCESSORIES

Dimpled Back of Sleeper Center Bar Trims	206
Daycab Rear Window Trims	206
Sleeper Rear Window Trims	206
Load Light Trims	207
Cab Vent Covers	207
Cab Double Vent Covers	207
Daycab Vertical Grab Handle Trim	207
Vertical Grab Handle Trim	207
Sleeper Shock Covers	207
Sleeper Side Vent Covers and Trims	207
Dimpled Side Vent Surround	207
Replacement Tail Light Panel	207

## KENWORTH

### T880 CAB PANELS / SLEEPER PANELS

3" Face Cab Panels - No Stacks	209
3" Face Cab Panels - Passenger Side Stacks	209
3" Face Cab Panels - Dual Stacks	209
3" Face Daycab Cab Panels - No Stacks	209
3" Face Daycab Cab Panels - Passenger Side Stacks	209
3" Face Daycab Cab Panels - Dual Stacks	209

### T680 SLEEPER PANELS

76" Sleeper Panels with Extensions High Slpr Roof Only	210
76" Sleeper Panels No Extensions High Slpr Roof Only	210
76" Sleeper Panels with Extensions No Stacks	210
76" Sleeper Panels No Extensions No Stacks	210
76" Sleeper Panels with Extensions Dual Stacks	210
76" Sleeper Panels No Extensions Dual Stacks	210
52" Sleeper Panels with Extensions Passenger Side Stack Only	211
52" Sleeper Panels No Extensions Passenger Side Stack Only	212
52" Sleeper Panels with Extensions No Stacks	211
52" Sleeper Panels No Extensions No Stacks	212
52" Sleeper Panels with Extensions Dual Stacks	211
52" Sleeper Panels No Extensions Dual Stacks	212
40" Sleeper Panels with Extensions Passenger Side Stack Only	213
40" Sleeper Panels No Extensions Passenger Side Stack Only	213
40" Sleeper Panels with Extensions No Stacks	213
40" Sleeper Panels No Extensions No Stacks	213
40" Sleeper Panels with Extensions Dual Stacks	213
40" Sleeper Panels No Extensions Dual Stacks	213

### T680 / T880 INTERIOR ACCESSORIES

Headliner Area Trims	214
Main Dash / Gauge Cluster Trims	214
Driver Side End Dash / Left and Right of Steering Colum	214
Top of Console Trims	214
Ignition Area Trims	214
Cab Door Handle Trims	215
Power Window Trims	215
Interior Cab Storage Door Covers	215
Cab Door Speaker Trims	215
Interior Sleeper Vent Trim	215
Shifter Boot Trim	215
Sleeper Control Panel Trim	215

### KENWORTH INTERIOR ACCESSORIES

Driver Side Interior Trims	222
Passenger Side Interior Trims	222
Interior Trims [2002 - 2004]	222
Center Console Without Cutout for Power Mirror Controls	222
Center Console With Cutout for Power Mirror Controls	222
Headliner Trims [1995 - 2004]	223
Covers	223
Glove Box Trims	223
Interior Trims	224
Console Trims	224
Headliner Trims [2001 and Earlier]	224
Interior Trims [2008 and Newer]	225