

**FLAT TOP BLIND MOUNT VISORS**

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

**13.5" BLIND MOUNT DROP VISOR [Kit]**

A. Blank (0)	35026-PC	N35026-PC
B. 3/4 Button (10)	35026LT0-PC	N35026LT0-PC
Bulls-Eye (10)	35026LT1-PC	N35026LT1-PC

**BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]**

Monster Drop Bow-Tie	35034-PC	N35034-PC
----------------------	----------	-----------

**11" BLIND MOUNT DROP VISOR [Kit]**

Blank (0)	35027-PC	N35027-PC
3/4 Button (10)	35027LT0-PC	N35027LT0-PC
Bulls-Eye (10)	35027LT1-PC	N35027LT1-PC

**BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]**

C. Regular Drop Bow-Tie Visor	35035-PC	N35035-PC
-------------------------------	----------	-----------

**FLAT TOP / ULTRA CAB BLIND MOUNT VISORS**

Fits Both Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

14" Blind Mount Drop Visor

D. 35065-PC	N35065-PC
-------------	-----------

Blind Mount Monster Drop Bow-Tie Visor

35066-PC	N35066-PC
----------	-----------

11" Blind Mount Drop Visor

35067-PC	N35067-PC
----------	-----------

Blind Mount Regular Drop Bow-Tie Visor

35068-PC	N35068-PC
----------	-----------

**ULTRACAB BLIND MOUNT VISORS**

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

**14.5" BLIND MOUNT DROP VISOR [Kit]**

Blank (0)	35022-PC	N35022-PC
3/4 Button (10)	35022LT0-PC	N35022LT0-PC
Bulls-Eye (10)	35022LT1-PC	N35022LT1-PC

**BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]**

E. Monster Drop Bow-Tie	35030-PC	N35030-PC
-------------------------	----------	-----------



*Ultracab Pride and Class Visors continued next page.*





**F**

**ULTRACAB BLIND MOUNT VISORS**

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

**11" BLIND MOUNT DROP VISOR [Kit]**

<b>F.</b>	Blank (0)	<b>35023-PC</b>	<b>N35023-PC</b>
<b>G.</b>	3/4 Button (10)	<b>35023LT0-PC</b>	<b>N35023LT0-PC</b>
	Bulls-Eye (10)	<b>35023LT1-PC</b>	<b>N35023LT1-PC</b>

**BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]**

<b>H.</b>	Regular Drop Bow-Tie Visor	<b>35031-PC</b>	<b>N35031-PC</b>
-----------	----------------------------	-----------------	------------------



**G**

**DARWIN VISORS**

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. [2014 & Newer] (Kit)

**DARWIN 10.5" DROP VISOR [Kit]**

<b>I.</b>	Blank (0)	<b>35570-PC</b>	<b>N35570-PC</b>
	3/4 Button (10)	<b>35570LT0-PC</b>	<b>N35570LT0-PC</b>
	Bulls-Eye (10)	<b>35570LT1-PC</b>	<b>N35570LT1-PC</b>



**H**



**I**



**J**

**DARWIN BOW-TIE DROP VISOR [Kit]**

<b>J.</b>	Darwin Bow-Tie Visor	<b>35582-PC</b>	<b>N35582-PC</b>
-----------	----------------------	-----------------	------------------

**UN-TIE DARWIN VISORS**

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. [2014 & Newer] (Kit)

**DARWIN 10.5" TO 6" UN-TIE VISOR [Kit]**

<b>K.</b>	Blank (0)	<b>35575-PC</b>	<b>N35575-PC</b>
	Front Lights		
	3/4 Button (10)	<b>35575LT0-PC</b>	<b>N35575LT0-PC</b>
	Front Lights		
<b>L.</b>	Bulls-Eye (10)	<b>35575LT1-PC</b>	<b>N35575LT1-PC</b>
	Top Lights		
	3/4 Button (10)	<b>35575LT2-PC</b>	<b>N35575LT2-PC</b>
	Top Lights		
	Bulls-Eye (10)	<b>35575LT3-PC</b>	<b>N35575LT3-PC</b>



**K**



**L**

**N** \*The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

**MULTI-FIT ULTRACAB AND FLAT TOP  
BLIND MOUNT VISORS**

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

**14" MULTIFIT BLIND MOUNT DROP VISOR [Kit]**

- A.**

Blank (0)	<b>35075-PC</b>	<b>N35575-PC</b>
3/4 Button (10)	<b>35075LT0-PC</b>	<b>N35075LT0-PC</b>
- B.**

Bulls-Eye (10)	<b>35075LT1-PC</b>	<b>N35075LT1-PC</b>
----------------	--------------------	---------------------



**BLIND MOUNT MONSTER DROP BOW-TIE  
DROP VISOR [Kit]**

- C.**

Monster Drop Bow-Tie	<b>35076-PC</b>	<b>N35076-PC</b>
----------------------	-----------------	------------------



**11" MULTIFIT BLIND MOUNT DROP VISOR [Kit]**

- Blank (0) **35077-PC** **N35077-PC**
- 3/4 Button (10) **35077LT0-PC** **N35077LT0-PC**
- Bulls-Eye (10) **35077LT1-PC** **N35077LT1-PC**

**BLIND MOUNT REGULAR DROP BOW-TIE  
DROP VISOR [Kit]**

- D.**

Regular Drop Bow-Tie Visor	<b>35078-PC</b>	<b>N35078-PC</b>
----------------------------	-----------------	------------------



**BLIND MOUNT SUPER UN-TIE DROP VISOR [Kit]**

- Super Un-Tie Drop Visor **35085-PC** **N35085-PC**

**FLAT TOP VISORS - STANDARD MOUNT**

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

- Factory-Style Extended 11" Visor  
**35061-PC** **N35061-PC**
- 13.5" Drop Visor  
**35057-PC** **N35057-PC**
- Monster Drop Bow-Tie Visor  
**35058-PC** **N35058-PC**
- 11" Drop Visor  
**35059-PC** **N35059-PC**
- Regular Drop Bow-Tie Visor  
**35060-PC** **N35060-PC**

