

FLAT TOP BLIND MOUNT VISORS

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

13.5" BLIND MOUNT DROP VISOR [Kit]

A. Blank (0)	35026-PC	N35026-PC
B. 3/4 Button (10)	35026LT0-PC	N35026LT0-PC
Bulls-Eye (10)	35026LT1-PC	N35026LT1-PC

BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

Monster Drop Bow-Tie	35034-PC	N35034-PC
----------------------	----------	-----------

11" BLIND MOUNT DROP VISOR [Kit]

Blank (0)	35027-PC	N35027-PC
3/4 Button (10)	35027LT0-PC	N35027LT0-PC
Bulls-Eye (10)	35027LT1-PC	N35027LT1-PC

BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

C. Regular Drop Bow-Tie Visor	35035-PC	N35035-PC
-------------------------------	----------	-----------

FLAT TOP / ULTRA CAB BLIND MOUNT VISORS

Fits Both Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

14" Blind Mount Drop Visor	35065-PC	N35065-PC
Blind Mount Monster Drop Bow-Tie Visor	35066-PC	N35066-PC
11" Blind Mount Drop Visor	35067-PC	N35067-PC
Blind Mount Regular Drop Bow-Tie Visor	35068-PC	N35068-PC

ULTRACAB BLIND MOUNT VISORS

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

14.5" BLIND MOUNT DROP VISOR [Kit]

Blank (0)	35022-PC	N35022-PC
3/4 Button (10)	35022LT0-PC	N35022LT0-PC
Bulls-Eye (10)	35022LT1-PC	N35022LT1-PC

BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

E. Monster Drop Bow-Tie	35030-PC	N35030-PC
-------------------------	----------	-----------



Ultracab Pride and Class Visors continued next page.





F

ULTRACAB BLIND MOUNT VISORS

Fits Peterbilt Pride and Class 388 and 389. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

11" BLIND MOUNT DROP VISOR [Kit]

F.	Blank (0)	35023-PC	N35023-PC
G.	3/4 Button (10)	35023LT0-PC	N35023LT0-PC
	Bulls-Eye (10)	35023LT1-PC	N35023LT1-PC

BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

H.	Regular Drop Bow-Tie Visor	35031-PC	N35031-PC
-----------	----------------------------	-----------------	------------------



G

DARWIN VISORS

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. [2014 & Newer] (Kit)

DARWIN 10.5" DROP VISOR [Kit]

I.	Blank (0)	35570-PC	N35570-PC
	3/4 Button (10)	35570LT0-PC	N35570LT0-PC
	Bulls-Eye (10)	35570LT1-PC	N35570LT1-PC



H



I



J

DARWIN BOW-TIE DROP VISOR [Kit]

J.	Darwin Bow-Tie Visor	35582-PC	N35582-PC
-----------	----------------------	-----------------	------------------

UN-TIE DARWIN VISORS

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. [2014 & Newer] (Kit)

DARWIN 10.5" TO 6" UN-TIE VISOR [Kit]

K.	Blank (0)	35575-PC	N35575-PC
	Front Lights		
	3/4 Button (10)	35575LT0-PC	N35575LT0-PC
	Front Lights		
L.	Bulls-Eye (10)	35575LT1-PC	N35575LT1-PC
	Top Lights		
	3/4 Button (10)	35575LT2-PC	N35575LT2-PC
	Top Lights		
	Bulls-Eye (10)	35575LT3-PC	N35575LT3-PC



K



L

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

MULTI-FIT ULTRACAB AND FLAT TOP BLIND MOUNT VISORS

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

14" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

A.	Blank (0)	35075-PC	N35575-PC
	3/4 Button (10)	35075LT0-PC	N35075LT0-PC
B.	Bulls-Eye (10)	35075LT1-PC	N35075LT1-PC

BLIND MOUNT MONSTER DROP BOW-TIE DROP VISOR [Kit]

C.	Monster Drop Bow-Tie	35076-PC	N35076-PC
-----------	----------------------	-----------------	------------------

11" MULTIFIT BLIND MOUNT DROP VISOR [Kit]

	Blank (0)	35077-PC	N35077-PC
	3/4 Button (10)	35077LT0-PC	N35077LT0-PC
	Bulls-Eye (10)	35077LT1-PC	N35077LT1-PC

BLIND MOUNT REGULAR DROP BOW-TIE DROP VISOR [Kit]

D.	Regular Drop Bow-Tie Visor	35078-PC	N35078-PC
-----------	----------------------------	-----------------	------------------

BLIND MOUNT SUPER UN-TIE DROP VISOR [Kit]

	Super Un-Tie Drop Visor	35085-PC	N35085-PC
--	-------------------------	-----------------	------------------

FLAT TOP VISORS - STANDARD MOUNT

Fits Peterbilt Pride and Class 388, 389 Flat Top and Ultra Cab. Add an "L" to your part number to order a louvered visor. [2014 & Newer] (Kit)

	Factory-Style Extended 11" Visor	35061-PC	N35061-PC
--	----------------------------------	-----------------	------------------

13.5" Drop Visor

E.	35057-PC	N35057-PC
-----------	-----------------	------------------

Monster Drop Bow-Tie Visor

	35058-PC	N35058-PC
--	-----------------	------------------

11" Drop Visor

F.	35059-PC	N35059-PC
-----------	-----------------	------------------

Regular Drop Bow-Tie Visor

G.	35060-PC	N35060-PC
-----------	-----------------	------------------

