



**567 / 579 15.5 INCH DROP VISOR** Does not fit Flat Top or Daycab. Fits Mid Roof and Hi-Rise Sleepers. [2013 & Newer] (Kit)

Blank (0)	38100	N38100
Supernova (8)	38101	N38101
Crew (8)	38103	N38103
2" Round Flat (10)	38104B	N38104B
2" Round Beehive (10)	38105B	N38105B
Challenger (10)	38109B	N38109B
Bulls-Eye (10)	38110B	N38110B
Bulls-Eye (10) *ID Pattern	38112BID	N38112BID
3/4" Button (10)	38110GB	N38110GB
Fusion (10)	38111BC	N38111BC
M1 (8)	38101M1	N38101M1
M3 (10)	38104M3	N38104M3
M5 (10)	38109M5	N38109M5
<b>G.</b> Mini (10)	38109MN	N38109MN

**567 / 579 13 INCH DROP VISOR** Does not fit Flat Top or Daycab. Fits Mid Roof and Hi-Rise Sleepers. [2013 & Newer] (Kit)

Blank (0)	38120	N38120
Supernova (8)	38121	N38121
Crew (8)	38123	N38123
2" Round Flat (10)	38124B	N38124B
2" Round Beehive (10)	38125B	N38125B
Challenger (10)	38129B	N38129B
Bulls-Eye (10)	38130B	N38130B
Bulls-Eye (10) *ID Pattern	38132BID	N38132BID
3/4" Button (10)	38130GB	N38130GB
Fusion (10)	38131BC	N38131BC
M1 (8)	38121M1	N38121M1
M3 (10)	38124M3	N38124M3
<b>H.</b> M5 (10)	38129M5	N38129M5
Mini (10)	38129MN	N38129MN

**567 / 579 15.5 INCH UN-TIE DROP VISOR** Fits Mid Roof and Hi-Rise Sleepers. [2013 & Newer] (Kit)

Blank (0)	38100UT	N38100UT
Supernova (8)	38101UT	N38101UT
Crew (8)	38103UT	N38103UT
2" Round Flat (10)	38104UTB	N38104UTB
2" Round Beehive (10)	38105UTB	N38105UTB
Challenger (10)	38109UTB	N38109UTB
Bulls-Eye (10)	38110UTB	N38110UTB
Bulls-Eye (10) *ID Pattern	38112UTBID	N38112UTBID
3/4" Button (10)	38110UTGB	N38110UTGB
Fusion (10)	38111UTBC	N38111UTBC
M1 (8)	38101UTM1	N38101UTM1
M3 (10)	38104UTM3	N38104UTM3
M5 (10)	38109UTM5	N38109UTM5
<b>I.</b> Mini (10)	38109UTMN	N38109UTMN

**567 / 579 REPLACEMENT DROP VISORS** For Daycab or Flat Top trucks with factory stainless visor. Will not fit trucks without factory visor. (Kit)

567 / 579 Replacement Drop Visor - Flat Top

<b>J.</b>	38135	N38135
	567 / 579 Replacement Un-Tie Drop Visor - Flat Top	
<b>K.</b>	38136	N38136

### 567 / 579 15.5 INCH DROP VISOR

Does not fit Flat Top or Daycab. [2013 & Newer] (Kit)

Blank (0)	38100	N38100
Supernova (8)	38101	N38101
Crew (8)	38103	N38103
2" Round Flat (10)	38104B	N38104B
2" Round Beehive (10)	38105B	N38105B
Challenger (10)	38109B	N38109B
Bulls-Eye (10)	38110B	N38110B
Bulls-Eye (10) *ID Pattern	38112BID	N38112BID
3/4" Button (10)	38110GB	N38110GB
Fusion (10)	38111BC	N38111BC
M1 (8)	38101M1	N38101M1
M3 (10)	38104M3	N38104M3
M5 (10)	38109M5	N38109M5
A. Mini (10)	38109MN	N38109MN



### 567 / 579 13 INCH DROP VISOR

Does not fit Flat Top or Daycab. [2013 & Newer] (Kit)

Blank (0)	38120	N38120
Supernova (8)	38121	N38121
Crew (8)	38123	N38123
2" Round Flat (10)	38124B	N38124B
2" Round Beehive (10)	38125B	N38125B
Challenger (10)	38129B	N38129B
Bulls-Eye (10)	38130B	N38130B
Bulls-Eye (10) *ID Pattern	38132BID	N38132BID
3/4" Button (10)	38130GB	N38130GB
Fusion (10)	38131BC	N38131BC
M1 (8)	38121M1	N38121M1
M3 (10)	38124M3	N38124M3
M5 (10)	38129M5	N38129M5
Mini (10)	38129MN	N38129MN



### 567 / 579 REPLACEMENT DROP VISORS

For Daycab or Flat Top trucks with factory stainless visor. Will not fit trucks without factory visor. (Kit)

B. 567 / 579 Replacement 11" Drop Visor - Flat Top	38135	N38135
567 / 579 Replacement Un-Tie 11" Outer / 9" Center Drop Visor - Flat Top	38136	N38136

See pages 77 and 128 for more 567/579 Visors.

### 579 INTAKE SCREEN

Replace **XX** in the grille part number with a punch from the punch options table. 39915-40 shown. (Pair)

C. Intake Replacement Screen	39915-XX	N39915-XX
------------------------------	----------	-----------



### PUNCH OPTIONS

View punch styles inside back cover.

-23	Small 1/4" Circles
-24	Large 7/16" Circles
-28	Hexagons
-30	Horizontal Rectangles
-31	Vertical Rectangles
-32	5/16" In-Line Squares
-33	5/16" Offset Squares
-36	Horizontal Oval Holes
-37	Vertical Ovals
-38	Horizontal 3/16" Oblong
-39	Vertical 3/16" Oblong
-40	Horizontal 5/16" Oblong
-41	Vertical 5/16" Oblong
-46	Stars
-47	Snake Skin

### 579 FENDER TRIMS Fits long hood. (Pair)

4 Piece Fender Trim - (No Light Hole)	39014	N39014
D. 1 - Tape Mount - (Mounts on Hood)	39015	N39015
2 - Tape Mount - (Mounts on Cab Fairing)	39016	N39016

