



386 2.25" CAB PANELS with Fairings and Rear or Horizontal Exhaust. Will not fit trucks without fairings, with side stacks, or day cab.

Blank (0)	36640	N36640
Supernova (8)	36641	N36641
Crew (8)	36643	N36643
Challenger (12)	36649	N36649
E. Bulls-Eye (12)	36644	N36644
3/4" Button (12)	36644GB	N36644GB
M1 (8)	36641M1	N36641M1
M3 (12)	36642M3	N36642M3
M5 (8)	36649M5	N36649M5
Mini (8)	36649MN	N36649MN



386 CAB PANELS with Dual Side Exhaust and Keworth Style Dpf Box [2011 & Newer]

DRIVERS SIDE CAB PANEL 40.5"
PASSENGER SIDE CAB PANEL 34.875"

Blank (0)	36780	N36780
Supernova (6)	36781	N36781
Crew (6)	36783	N36783
2" Round Flat (10)	36784	N36784
Challenger (10)	36789	N36789
Bulls-Eye (10)	36790	N36790
3/4" Button (10)	36790GB	N36790GB
Fusion (10)	36791C	N36791C
F. M1 (6)	36781M1	N36781M1
M3 (10)	36782M3	N36782M3
M5 (10)	36789M5	N36789M5
Mini (10)	36789MN	N36789MN

386 CAB PANEL 3.375" FACE with Dual Side Exhaust and Non Keworth Style Dpf Box. [2010 & Older] Will not fit trucks with fairings.

DRIVERS SIDE CAB PANEL 40.5"
PASSENGER SIDE CAB PANEL 36.188"

Blank (0)	36720	N36720
Supernova (6)	36721	N36721
Crew (6)	36723	N36723
2" Round Flat (10)	36724	N36724
2" Round Beehive (10)	36725	N36725
Challenger (10)	36729	N36729
Bulls-Eye (10)	36730	N36730
3/4" Button (10)	36730GB	N36730GB
Fusion (10)	36731C	N36731C
M1 (6)	36721M1	N36721M1
M3 (10)	36724M3	N36724M3
M5 (10)	36729M5	N36729M5
Mini (10)	36729MN	N36729MN

See page 139 for more 386 Cab Panel Options.



387 CAB PANELS Fits sleeper trucks. Will not fit day cab. Mounts to the bottom of the door. (Pair)

Blank (0)	36600	N36600
Supernova (6)	36601	N36601
Crew (6)	36603	N36603
G. 2" Round Flat (12)	36604B	N36604B
2" Round Beehive (12)	36605B	N36605B
Challenger (12)	36609B	N36609B
Bulls-Eye (12)	36610B	N36610B
3/4" Button (12)	36610GB	N36610GB
Fusion (12)	36611BC	N36611BC
M1 (6)	36601M1	N36601M1
M3 (12)	36604M3	N36604M3
M5 (12)	36609M5	N36609M5
Mini (12)	36609MN	N36609MN



587 CAB PANELS Fits sleeper trucks with fairings. Will not fit day cab. Mounts to cab. (Pair)

Blank (0)	38000	N38000
Supernova (6)	38001	N38001
Crew (6)	38003	N38003
2" Round Flat (8)	38004B	N38004B
2" Round Beehive (8)	38005B	N38005B
Challenger (8)	38009B	N38009B
Bulls-Eye (8)	38010B	N38010B
3/4" Button (8)	38010GB	N38010GB
Fusion (8)	38011BC	N38011BC
M1 (6)	38001M1	N38001M1
M3 (8)	38004M3	N38004M3
M5 (8)	38009M5	N38009M5
Mini (8)	38009MN	N38009MN

For Heater Plug Hole call RoadWorks Customer Service at 1-800-448-8741.

N *The part numbers beginning with 'N' in the right-sided column designate 304 stainless material. 304 stainless has enhanced corrosion resistance.

387 CAB PANELS - Fits sleeper trucks. Will not fit day cabs. Mounts to the bottom of the door. (Pair)

	Blank (0)	36600	N36600
	Supernova (6)	36601	N36601
	Crew (6)	36603	N36603
A.	2" Round Flat (12)	36604B	N36604B
	2" Round Beehive (12)	36605B	N36605B
	Challenger (12)	36609B	N36609B
	Bulls-Eye (12)	36610B	N36610B
	3/4" Button (12)	36610GB	N36610GB
	Fusion (12)	36611BC	N36611BC
	M1 (6)	36601M1	N36601M1
	M3 (12)	36604M3	N36604M3
	M5 (12)	36609M5	N36609M5
	Mini (12)	36609MN	N36609MN



387 DAY CAB PANELS - Will not fit sleeper trucks. Mounts to the bottom of the door. (Pair)

	Blank (0)	36620	N36620
	Supernova (8)	36621	N36621
B.	Crew (8)	36623	N36623
	2" Round Flat (12)	36624B	N36624B
	2" Round Beehive (12)	36625B	N36625B
	Challenger (12)	36629B	N36629B
	Bulls-Eye (12)	36630B	N36630B
	3/4" Button (12)	36630GB	N36630GB
	Fusion (12)	36631BC	N36631BC
	M1 (8)	36621M1	N36621M1
	M3 (12)	36624M3	N36624M3
	M5 (12)	36629M5	N36629M5
	Mini (12)	36629MN	N36629MN



This image shows the rear view of the cab panel as it wraps the back of the cab.

387 SLEEPER PANELS - Sleeper Panels fit Stand-Up Sleeper models only. Does not fit Mid Roof or Low Roof models. (Pair)

STANDARD SLEEPER

	Blank (0)	37620	N37620
	Supernova (12)	37621	N37621
	Crew (12)	37623	N37623
	2" Round Flat (22)	37624B	N37624B
	2" Round Beehive (22)	37625B	N37625B
	Challenger (22)	37629B	N37629B
	Bulls-Eye (22)	37630B	N37630B
	3/4" Button (22)	37630GB	N37630GB
	Fusion (22)	37631BC	N37631BC
	M1 (12)	37621M1	N37621M1
	M3 (22)	37624M3	N37624M3
	M5 (22)	37629M5	N37629M5
	Mini (22)	37629MN	N37629MN



PREMIUM SLEEPER - (Includes heater plug hole on driver's side sleeper panel.)

	Blank (0)	37600	N37600
	Supernova (14)	37601	N37601
	Crew (14)	37603	N37603
C.	2" Round Flat (26)	37604B	N37604B
	2" Round Beehive (26)	37605B	N37605B
	Challenger (26)	37609B	N37609B
	Bulls-Eye (26)	37610B	N37610B
	3/4" Button (26)	37610GB	N37610GB
	Fusion (26)	37611BC	N37611BC
	M1 (14)	37601M1	N37601M1
	M3 (26)	37604M3	N37604M3
	M5 (26)	37609M5	N37609M5
	Mini (26)	37609MN	N37609MN



To identify a Premium Sleeper look for the extra section at the front of the sleeper area, located directly behind the curved section that meets the rear of the cab, and is separated from the rest of the sleeper by the vertical separations you see in the picture. Standard sleepers do not have the extra section.

Call RoadWorks Customer Service at 1-800-448-8741 for information on Sleeper Panels for Mid Roof and Low Roof model sleepers.