

# 1998 & EARLIER ULTRA CAB REPLACEMENT VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.  
Remove factory visor and brackets. Drill out factory holes to 1/2"  
Install new brackets in factory locations using supplied hardware.  
Fasten visor skins to brackets using supplied hardware.

35006-IN  
USE FOR 35006

4 Brackets included

