

2002-2005 WITH DOOR MOUNTED MIRRORS ULTRA CAB DROP VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.
Remove factory visor and brackets. Drill out factory holes to 1/2"
Install new brackets in factory locations using supplied hardware.
Fasten visor skins to brackets using supplied hardware.

35013-IN
USE FOR 35013,
35013L, 35014

