

2005 & NEWER ULTRA CAB WITH CAB MOUNTED MIRRORS DROP VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.
Remove factory visor and brackets. Drill out factory holes to 1/2"
Install new brackets in factory locations using supplied hardware.
Fasten visor skins to brackets using supplied hardware.

35018-IN
USE FOR 35018, 35018L
35019

