

1988-2005 FLAT TOP CAB WITH DOOR MOUNTED MIRRORS DROP VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.
Remove factory visor and brackets. Drill out factory holes to 1/2"
Install new brackets in factory locations using supplied hardware.
Fasten visor skins to brackets using supplied hardware.

35053-IN
USE FOR 35053, 35053L, 35054

