

# 2005 & NEWER FLAT TOP WITH CAB MOUNTED MIRRORS DROP VISOR INSTRUCTIONS

35057-IN  
USE FOR 35057 ,35057L, 35058

VERIFY the factory brackets are in the location listed below.  
Remove factory visor and brackets. Drill out factory holes to 1/2"  
Install new brackets in factory locations using supplied hardware.  
Fasten visor skins to brackets using supplied hardware.

